FUEL INJECTED CESSNA 172 CHECKLIST

FUEL INJECTED CESSNA 172 CHECKLIST

FUEL INJECTED CESSNA 172 CHECKLIST

• Fuel

CHECK (122.85)

CABIN CHECK

Ignition Key
 Documents (AROW)
 Hobbs Meter
 Control Lock
 MON GLARESHIELD
 CHECK
 CHECK TIME
 REMOVE

Electrical & Avionics
 Master Switch

Avionics Master Switch
 Annunciator Panel Switch
 TEST LIGHTS

Fuel Gauges
 Flaps
 Exterior Lights
 Master Switch
 Parking Brake

CHECK
ON

EXTERIOR INSPECTION

 Fuel Sumps SAMPLE (5) Fuselage Left Side CHECK · Elevator/Rudder CHECK Tail Tie-down REMOVE Fuselage Right Side CHECK · Right Flap & Aileron CHECK · Wing Tie-down **REMOVE** Fuel Sumps SAMPLE (5) Main Wheel Tire/Brakes CHECK · Chocks **REMOVE**

 Fuel Quantity (Right Tank)
 Engine Oil Level
 CHECK VISUALLY CHECK (MIN. 5 QTS)

Fuel Strainer/Selector Drains
 Propeller & Spinner
 SAMPLE (2)
 CHECK

Alternator BeltLanding LightCHECK (CONDITION)

Engine Air-Intake Filter
 Nose Wheel Strut & Tire
 Nose Chocks
 Static Source
 CHECK
 REMOVE
 CHECK

• Fuel Quantity (Left Tank) CHECK VISUALLY

Wing Tie-down
 Pitot Tube Cover
 Fuel Tank Vent
 Stall Warning Horn Opening
 Left Flap & Aileron
 Main Wheel Tire/Brakes
 CHECK
 CHECK
 CHECK

Main Wheel Tire/Brakes
 Chocks
 Move Airplane
 CHECK REMOVE
 CHECK TIRES

Overall Condition REVIEW

BEFORE ENGINE START

 Seatbelts/Shoulder Harness **FASTENED** Brakes **TEST & SET** Fuel Selector BOTH Fuel Shutoff Valve ON (IN) Circuit Breakers CHECK Beacon ON · Avionics Switch OFF Master Switch ON

• Throttle OPEN 1/4 INCH

Mixture
 Aux. Pump
 Mixture Rich 3-5 GPH
 Aux. Pump
 Propeller Area
 IDLE CUTOFF
 CUT OFF
 CUT OFF
 CLEAR

AFTER ENGINE START

Ignition Switch
Mixture (At Engine Start)
Engine RPM
Oil Pressure
Mixture
Mixture
Flaps
START
RICH
1000 RPM
CHECK
LEANED MAX
RETRACT

TAXI

Brakes CHECK
 Magnetic Compass MOVEMENT FREE
 Flight Instruments CHECK

BEFORE TAKEOFF

Parking Brakes
 Flight Controls
 FREE & CORRECT
 Flight Instruments
 Fuel Selector
 Elevator & Rudder Trim
 SET

Mixture
 Autopilot
 Throttle
 Ammeter
 Engine Instruments.
 Suction
 RICH FOR RUNUP
 CHECK DISCONNECT
 1800 RPM
 CHECK
 CHECK
 CHECK

Magnetos CHECK (125/50)
 Throttle IDLE CHECK

SMOOTH & 600 RPM ± 25 THEN1000 RPM
• Radios SET
• Brakes RELEASE

TAKEOFF

"LIGHTS" (ALL) ON
"CAMERA" (Transponder) ON
"ACTION" (RPM, Oil Pres., Time)
Climb Speed (172R) 74 KTS (172S) 79 KTS

BEFORE LANDING

Seatbelts	ADJUST
Fuel Selector	BOTH
Engine Gauges	CHECK
Heading Indicator	ALIGNED
Altimeter Setting	CHECK
Radios	SET
 Autopilot 	OFF

---- Final Items

Mixture RICHFlaps DOWNApproach Speed 65-75 KTS

AFTER LANDING CHECK

• "LIGHTS" (Except Beacon) OFF • "CAMERA" (Transponder) OFF

• "ACTION" (Mixture, Flaps)

ENGINE SHUTDOWN

Throttle
Mags
Throttle
Avionics/Electrical Equip.
Mixture
Master/Alternator Switch
Ignition Switch
IDLE
GROUND CHECK
1000 RPM
OFF
CUTOFF
OFF
OFF

SECURING AIRCRAFT

Ignition Key

Hobbs & Tach
 Control Lock
 Tiedowns/Chocks
 Propeller (For Fuel)
 Fuel
 RECORD
 INSTALL
 INSTALL
 VERTICAL
 RIGHT TANK

GLARESHIELD

PROCEDURES > ン Z Ш C 2 Ш Ш

AIRSPEEDS FOR EMERGENCY OPERATIONS

65 KTS Engine Failure After Takeoff

Maneuvering Speed: 2450 LBS/99KTS • 2100 Lbs/92 KTS • 1600 Lbs/82 KTS 65 KTS

Maximum Glide

Landing Without Engine Power:

Flaps Down 60 KTS Flaps Up 65 KTS

ENGINE FAILURE IMMEDIATELY AFTER TAKEOFF

BOTH RICH Fuel Selector

Mixture

IF ENGINE FAILS TO RESTART

CUTOFF 65 KTS Airspeed Mixture

OFF (PULL OUT) 9FF Fuel Shutoff Valve

Ignition Switch

Master Switch

뜽

ENGINE FAILURE DURING FLIGHT

65 KTS FLY THE AIRPLANE Airspeed

(II) NO Fuel Shutoff Valve

Fuel Selector

BOTH

Aux. Fuel Pump

Mixture

Ignition Switch

BOTH

RICH

8

EMERGENCY LANDING WITHOUT POWER

Airspeed

OFF (PULL OUT) CUTOFF 65 KTS Fuel Shutoff Valve Mixture

Ignition Switch Wing Flaps

AS REQUIRED

PF.

Master Switch

Seatbelts Door

UNLATCH

TIGHT

님

Touchdown Brakes

SLIGHTLY TAIL LOW APPLY HEAVILY

ALTERNATOR FAILURE

OFF. Avionics Power Switch

CHECK IN OFF Alternator Circuit Breaker

Master Switch

Master Switch

Avionics Power Switch Low Voltage Light

CHECK OFF

8

8

IF LOW VOLTAGE LIGHT ON AGAIN

Alternator

Nonessential Electrical Equip Land As Soon As Practical

HO H H

FIRE DURING START OR GROUND

CONTINUE FOR START If Engine Fails To Start Cranking Throttle

Master Switch Mixture

Ignition Switch Fuel Shutoff Valve

Aux. Fuel Pump

(PULL OUT) FULL OPEN CUTOFF OFF # # # # OFF.

ENGINE FIRE IN FLIGHT

OFF (PULL OUT)
OFF CUTOFF Fuel Shutoff Valve Mixture

HO HO H Aux. Fuel Pump Master Switch

Cabin Heat & Air

BLOW OUT FIRE Increase Airspeed

EXECUTE Forced Landing

ELECTRICAL FIRE IN FLIGHT

뜽 Master Switch

OFF HO H Avionics

OFF/CLOSE All Other Switches Cabin Heat & Air

COMMUNICATION LOSS

CHECK Frequency

CHECK Volume/Squelch

CHECK SELECTION Speaker/Phones Switch

Headset Jacks

O/H Speaker-Handmike Circuit Breakers

TRY BOTH

RESET

CHECK

VOR Frequency Other Radio

IF AVAILABLE

MONITOR

Squawk

JBSERVE 2009 Tower Lights Signals

121.5 **EMERGENCY FREQUENCY**

CENTER County Orange FLIGHT

Santa Ana, CA 92707 (949) 756-1300 • Fax (949) 756-0727 www.ocflightcenter.com 19711 Campus Dr., #150

