
PROFESSIONAL SPEAKER BOX

USER'S MANUAL




Made in China

1.Welcome to choose our speaker.

2.Packing Contents


- 1×speaker
- 1×remote control
- 1×user's guide
- 1×power cable (1.5M)
- 1×Wireless Microphone

3.Speaker back panel




1. MIC INPUT control : Use this control to set the volume level of the microphone(6.3mm or balanced).
2. Microphone input : Allow to connect a balanced microphone with cannon or 6.3mm connector.
3. LINE INPUT control : Use this control to set the volume level of the line –in signal.
4. LINE INPUT : Use these RCA and cannon inputs to connect an external audio device CD, MP3 player ,DVD ,mixer ,etc.
5. TREBLE : Use it to set the treble level.
6. Bass : Use it to set the bass level.
7. General Volume Control : Use this control to set the general volume level.
8. Power indicator.
9. Over-load indicator : When the volume is very hard this LED will activate ,in this case . please reduce the volume level.
10.Signal output : Use this jack to connect other non-amplified in cascade ,using a speakon connector .
11. On/Off power switch.
12.AC power : Use it to connect the AC power cord.
13. Fuse.
14. Bluetooth (Select).

4.Wireless Microphone



1 Grille.
2 Power ON/OFF Switch. When battery is low ,the light will blink
3 Mic Mute switch."Mutes"the transmitter to prevent unwanted sounds from being picked up by the receiver without turning the transmitter off.
4 Battery Cover. Access to the battery .

5.MP3



- **SD card slot :** Use it to insert a SD card with Mp3 files.

- **Play /Pause :** Press to play a song or pause while playing a song.

- **Previous /Volume-:** Press once to jump previous song/Press and Hold to diminish the volume level.

- **Next/Volume +:**Press once to jump next song /press and hold to raise The volume level.

- **Cycle play:** To select a player mode , the options are:
  -One : Select this to play current song indefinitely
  -All : With this option you can repeat all music

- **Model :** Select an operating modality ,the options are SD or USB. FM Bluetooth.

- USB input.

Conection Bluetooth

1.To pair the speaker with a Bluetooth phone or audio device, press"MODE" repeatedly on the MP3 player until select this mode.

2. Put your phone or device to be used in Bluetooth device discovery mode.

3.When your phone or device shows the "BLUETOOTH" device, confirm the link.