

Education evenings 2018



Computer exercises
03 02 Particle tracking

1


Purpose


In this example, we will use the Rocky Mountain Arsenal model, one of the examples that come with ModelMuse, to set up

- ✓ forward particle tracking to visualize advective flow paths from a disposal pond, and
- ✓ backward particle tracking to map an (advective) well capture zone.

Copy example model


- ✓ Copy the model from the previous exercise "03-01_rma-examplemodel.mmZLib" to folder "/03-02_particle-tracking/",
- ✓ and rename the copied file to "03-02_particle-tracking.mmZLib".
- ✓ Another option is to copy file "03-01_rma-example-model.mmZLib" in folder "/06_solutions/".
- ✓ Double click the new file to open ModelMuse.





Enable MODPATH


- ✓ Select Model | MODFLOW Packages and Programs...,
- ✓ expand Post processors, and
- check the check box for MODPATH.
- Change the Output mode to Pathlines, and note we will be doing Forward tracking,
- ✓ and press OK.



E

Change head output file type

- ✓ Note you get a warning concerning the head output file type.
- ✓ Select Model | MODFLOW Output Control...,
- Choose Head, and set the External file type to Binary.
- ✓ Click **OK**.



Set the MODPATH program location


- ✓ Select Model | MODFLOW Program Locations, and
- ✓ fill in the path to the MODPATH
 executable for your machine
 architecture in folder
 "/05 software/modpath/".
- ✓ Then press **OK**.



7


Define initial particle placement

- Double click on the disposal pond object,
- and in the Object Properties dialog box, select MODFLOW Features, and click on MODPATH.
- ✓ Set the flow into the cell at the **Top** face, and
- put 5 by 5 particles at the **Top** face in the **Grid**.
- ✓ Then press **OK**.



Chance stress period duration


- ✓ Select Model | MODFLOW Time... and
- ✓ Set **Starting time** to 0,
- ✓ Ending time, Length and Max first time step length to 1E9.
- ✓ Then press OK.



q


Run model (1/2)


- ✓ Run MODFLOW by saving the MODFLOW input files.
- ✓ Note that the Export MODPATH input checkbox is selected as well, and
- check the Create new composite budget file checkbox.
- Press Save to save and run the model.



Run model (2/2)

- ✓ You can neglect the warnings and close the Errors and Warnings window.
- ✓ Note that when you close ModelMonitor, MODPATH will be launched as well.
- Close the command line window after it has finished.






11


Visualize pathlines (1/2)

- ✓ Select Data | Data Visualization... or use the corresponding button,
- ✓ and choose MODPATH Pathlines.
- ✓ Select the MODPATH pathline file "03-01_particle-tracking.path".




Visualize pathlines (2/2)

- ✓ Switch to the **Options** tab, and
- ✓ set the Color limits to 0 and 1E9.
- ✓ Then press **Apply**.




1:

This is what you should get



Rerun MODPATH without weak sinks (1/3)


- ✓ Select Model | MODFLOW Packages and Programs...,
- ✓ go to **MODPATH**,
- ✓ and set the Treatment of weak sinks to Stop.
- ✓ Then press OK.



15


Rerun MODPATH without weak sinks (2/3)

- ✓ Select File | Export | MODPATH Input Files,
- check the Execute model and
 Create new composite budget file checkboxes, and
- ✓ press Save.



Rerun MODPATH without weak sinks (3/3)


- ✓ Now update the visualization in the **Data Visualization** dialog box, by pressing **Apply**,
- ✓ and click Yes to import the new file.
- ✓ Can you see what has changed by stopping the particles at weak sinks?



17


Define particles at well cells

- ✓ Double click on each of the extraction well objects,
- ✓ go to the MODFLOW Features tab in the Object Properties dialog box, and
- ✓ set **IFACE** to **Internal**,
- ✓ the Initial particle placement
 to Grid and Internal, and
- ✓ use 5 by 5 by 5 rows.
- ✓ Then press **OK**.



Rerun MODPATH with backward tracking (1/3)


- ✓ Select Model | MODFLOW Packages and Programs...,
- ✓ go to **MODPATH**,
- ✓ set the Reference time for simulation to 1E9,
- ✓ and set the Tracking direction to Backward.
- ✓ Then press **OK**.



10


Rerun MODPATH with backward tracking (2/3)

- ✓ Select File | Export | MODPATH Input Files,
- check the Execute model and
 Create new composite budget file checkboxes, and
- ✓ press Save.




Rerun MODPATH with backward tracking (3/3)

- ✓ Now update the visualization in the **Data Visualization** dialog box, by pressing **Apply**,
- ✓ and click Yes to import the new file.



24

This is what you should get





Education evenings 2018

Practical introduction to groundwater modelling

Computer exercises 03 02 Particle tracking

Questions? Found an error?
Please contact B. Rogiers at brogiers@sckcen.be.