DKS-BASIC ESP32 RC CAR — ELECTRICAL SYSTEM

Version 1 · PS4 Bluetooth control · 3S LiPo · sensorless brushless drive

A3 · NTS

A · POWERTRAIN



B · CONTROL & LOW VOLTAGE



WIRE KEY

- Power & ground
- +5 V logic rail
- Signal (PWM)
- Wireless link

SAFETY & START-UP

1. Disconnect B1 before wiring or USB. Never connect the 3S rail to U1, SV1 or the 5 V bus.
2. Firmware must hold neutral throttle (~1500 µs) until ESC1 is armed, and on any loss of the controller link.
3. Commission with wheels raised at low throttle. To reverse direction, disconnect B1 and swap any two motor phases.

PROJECT	DRAWING	DOC	REV	DATE	STATUS
DKS-Basic ESP32 RC Car	Electrical System	RC-CAR-ELEC-V1	1.1	2026-08-27	RELEASE