TRENDING

Installing the Exodus Streaming Video Plugin for Kodi










Search...





HOME

CATEGORIES ~

BERRYCLIP ~

BUY ~

TOOLS ~

TUTORIALS & HELP

CONTACT US

SITE MAP

YOU ARE AT: Home » Hardware » How To Mount A USB Flash Disk On The Raspberry Pi

How To Mount A USB Flash Disk On The Raspberry Pi

Q 23

RECENT

POPULAR

NEWS

BY MATT ON MAY 21, 2014

HARDWARE, TUTORIALS & HELP



SEPTEMBER 3, 2017

IKEA Arcade Table Based On a

Raspberry Pi Running RetroPie



AUGUST 30, 2017

22

 $\bigcirc 0$

Send Pushover Notification when MotionEyeOS Boots



AUGUST 9, 2017

Q 0

Controlling Energenie Power Sockets with the Pi-mote Addon



JULY 26, 2017

 Q_0 0

KKSB Metal Cases for the Raspberry Pi 2 and 3

Whether you call them USB flash disks, memory sticks, keys or drives they are a useful accessory in the world of computers. By now many people will have a collection of various devices of varying capacities. Using them with the Pi is a great way of getting some use out of them rather than letting them gather dust in a drawer.

I tend to transfer files from my Pi using FTP but occasionally it is useful to get stuff onto a USB drive. There are lots of guides already out there but I had a few issues using most of them, mainly due to permission problems. My main goal was to clarify the process by which I could mount standard FAT32 drives and allow the default Pi user read/write permissions.



So here is my procedure for using USB flash drives with the Raspberry Pi where the Pi user has permissions to use it without needing "sudo". It works great with the shiney new Kingston Digital 32GB DataTraveler Micro I've just bought myself.

Step 1 - Plug In The Device

The first step is to plug in your USB stick. If you are using a mouse and keyboard you will need a decent USB hub at this point. (e.g. the PiHub by Pimoroni).



Step 2 - Identify The Devices Unique ID

In order to find the unique reference (UUID) for your drive run the following command in the terminal:

ls -l /dev/disk/by-uuid/

This will give you an output that should list your drive:





JULY 17, 2017

2 2

Pool Temperature Monitoring and Pump Control with the Pi Zero W

_		
500	rck	٦.
200		

3D Printing

Search

CATEGORIES

Add-ons
BBC Micro:bit
BerryClip
Books
Camera Module
Cases
Events
General
Hardware
12C
Infographics
Minecraft
Model A+
Model B+

```
pi@raspberrypi ~ $ ls -1 /dev/disk/by-uuid/
total 0
lrwxrwxrwx 1 root root 10 May 18 13:11 18A9-9943 -> ../../sda1
lrwxrwxrwx 1 root root 15 Jan 1 1970 993B-6922 -> ../../mmcblk0p1
lrwxrwxrwx 1 root root 15 May 18 13:11 fc254b57-8fff-4f96-9609-ea202d871acf -> ../../mmcblk0p2
pi@raspberrypi ~ $
```

The line will usually refer to "/sda" and in this example it is "sda1". My ID is "18A9-9943". Note down yours.

You would need to repeat this step if you wanted to use a different device as the UUID would be different.

Step 3 - Create a Mount Point

A mount point is a directory that will point to the contents of your flash drive. Create a suitable folder:

```
sudo mkdir /media/usb
```


I'm using "usb" but you can give it whatever name you like. Keep it short as it saves typing later on. Now we need to make sure the Pi user owns this folder:

```
sudo chown -R pi:pi /media/usb
```


You will only need to do this step once.

Step 4 - Manually Mount The Drive

To manually mount the drive use the following command:



TAGS



sudo mount /dev/sda1 /media/usb -o uid=pi,gid=pi

This will mount the drive so that the ordinary Pi user can write to it. Omitting the "-o uid=pi,gid=pi" would mean you could only write to it using "sudo".

Now you can read, write and delete files using "/media/usb" as a destination or source without needing to use sudo.

Step 5 - Un-mounting The Drive

You don't need to manually un-mount if you shutdown your Pi but if you need to remove the drive at any other time you should un-mount it first. Only the user that mounted the drive can un-mount it.

umount /media/usb

If you used the fstab file to auto-mount it you will need to use:

sudo umount /media/usb


If you are paying attention you will notice the command is "umount" NOT "unmount"!

Step 6 - Auto Mount

When you restart your Pi your mounts will be lost and you will need to repeat Step 4. If you want your USB drive to be mounted when the system starts you can edit the fstab file:

sudo nano /etc/fstab

Then add the following line at the end:



RASPBERRY PI RELATED

Averageman Vs Pi
MattsBits – Pi Resources
Official RaspBerry Pi Site
Raspberry Pi Pod
RasPi.tv
Raspihub.com
RaspTut
Rastrack.co.uk
RPi School

```
UUID=18A9-9943 /media/usb vfat auto,nofail,noatime,users,rw,uid=pi,gid=pi 0 0
```

The "nofail" option allows the boot process to proceed if the drive is not plugged in. The "noatime" option stops the file access time being updated every time a file is read from the USB stick. This helps improve performance.

My fstab file looks like this:

```
proc /proc proc defaults 0 0
/dev/mmcblk0p1 /boot vfat defaults 0 2
/dev/mmcblk0p2 / ext4 defaults,noatime 0 1
# a swapfile is not a swap partition, no line here
# use dphys-swapfile swap[on|off] for that
UUID=1810-3DF0 /media/usb vfat auto,nofail,noatime,users,rw,uid=pi,gid=pi 0 0
```

Make sure you set the correct UUID. Use CTRL-X followed by Y to save and exit the nano editor.

Now reboot:

sudo reboot

Your USB drive should be auto-mounted and available as "/media/usb".

An Extra Note About File Systems

In the examples above I specified "vfat" as the file system of the device as it was formatted as FAT32. If you need to change the file system replace references of "vfat" with "ntfs-3g", "ext3" or "ext4".

If you are using NTFS you will also need to install the following package:

sudo apt-get install ntfs-3g

Final Thoughts

TECH RESOURCES

How2Code Microbit Spy Technology Spy ARCHIVES

Archives Select Month \$

This technique suits my applications but the main disadvantage is that it is specific to a known USB device given we are using the device ID. However if you created a few mount points in advance you could manually mount a new device to a spare mount point without worrying about updating the fstab file.

SHARE.









◀ PREVIOUS ARTICLE

How to Setup the Minecraft Python API on a Raspberry Pi NEXT ARTICLE >

Getting Started With The Pi Co-op Arduino Raspberry Pi Addon

RELATED POSTS



AUGUST 30, 2017

Send Pushover Notification when MotionEyeOS Boots



JULY 17, 2017

Pool Temperature Monitoring and Pump Control with the Pi Zero W



Create a Basic Python Web Server with Flask

JUNE 4, 2017

Q 0

2 2

JUNE 3, 2017

Q 1

MAY 31, 2017

2 2

Installing the YouTube Video Plugin for Kodi Installing the Exodus Streaming Video Plugin for Kodi How to Create a New SD Card for Raspberry Pi on Windows

MAY 30, 2017

Q 0

APRIL 24, 2017



APRIL 18, 2017



Monitoring Raspberry Pi GPIO with MotionEyeOS

Detection Area Masking in motionEyeOS on the Raspberry Pi Raspberry Pi CCTV Camera with motionEyeOS

23 COMMENTS

GAWEN on MAY 21, 2014 4:52 PM

apt-get install pmount

Mount and umount sda1 as user:

- \$ pmount sda1
- \$ pumount sda1

You can also use an absolute path to the partition to leverage your shell's autocompletion (pmount /dev/sda1).

BTW if you want to automount your devices, you should use udisks rather than fstab, as you said the later requires you to manually add any new device to your fstab. I guess PCManFM supports automounting devices with udisks. If you don't use a file manager you can use udisks-glue instead as long as you have a DBus session.

REPLY >

JOSÉ CERREJÓN (@ULYSESS10) on MAY 22, 2014 9:18 AM

What about the package usbmount?

sudo apt-get install usbmount and you have /media/usb ready to any usb flash disk 🙂

REPLY >

MATT on MAY 22, 2014 8:24 PM

I found mentions of that package on Google but I was put off by the fact it is no longer maintained according to its homepage.

REPLY >

EDEN on MAY 26, 2014 8:34 PM

apt-get install pmount?

Or you use the "users" option in fstap! No need for pmount.

REPLY >

MATT on MAY 26, 2014 8:54 PM

The "users" option just allows other users to unmount the device. It doesn't allow the Pi user to write to it if it has been mounted by fstab.

REPLY >

JUNIOR on DECEMBER 7, 2014 7:27 PM

Is -I /dev/disk/by-uuid/

I only receive information from the SD card not from the nfts drive I tried mounted and unmounted with same result.

My drive is USB 3.0 1tb ext4

REPLY >

KARLDUINO on FEBRUARY 11, 2015 2:26 AM

For the automount to work for me, I needed to add a vfat , so that the line in /etc/fstab was: UUID=18A9-9943 /media/usb vfat auto,users,rw,uid=pi,gid=pi 0 0

REPLY >

PAUL on APRIL 3, 2015 4:50 AM

Same thing for me. I wonder how it could have worked for Matt without that, but he should add it to his example.

Also if you use something like ext4 you cannot use uid= or gid= so you have to fool around with chown or chmod commands. Better to just use vfat and never have a file over 4GB out there.

REPLY >

MATT on APRIL 3, 2015 11:03 AM

Hi Paul, I've put this post on my list for review!

REPLY >

JOSH on AUGUST 11, 2015 5:29 PM

If I wanted to run video capture of over 4gb could I mount the drive a different file system? perhaps by changing "vfat" to something different?

REPLY >

PETER on JUNE 7, 2015 12:24 AM

Great article – thanks for cutting through the syntax and putting forward a working method.

Cheers

REPLY >

JOHN on OCTOBER 23, 2015 5:08 PM

In your code, you've left out the third field, the fs vfstype. In the case of a USB key, I used vfat and was able to mount. Otherwise, it won't mount.

REPLY >

AEROSON on FEBRUARY 9, 2016 11:09 AM

After editing your "/etc/fstab" you should do "sudo mount -a" to verify that the modifications done are correct.

Because if they are wrong your system might not start and you will have to spend time fixing it on another system. (or finding software for Windows that facilitates access to linux filesystem, in order to fix the fstab)

REPLY >

RICHARD on AUGUST 3, 2016 12:09 AM

My usb drive was not mounting as expected, until I discovered that you omitted the 'vfat' parameter in the fstab file – as John pointed out. Attempting "sudo mount -a" displays the error.

REPLY >

MATT on AUGUST 23, 2016 10:01 PM

Just updated this post to deal with the last version of Raspbian. Added the "nofail" and "noatime" options as well the "vfat" file system type. Hopefully this will make the process more reliable for Raspbian "Jessie".

REPLY >

RICHARD on SEPTEMBER 5, 2016 7:58 AM

Неу,

I've got an idea,

How about making it easy.

Every single time I set up a raspberry pi system, I have to deal with this rubbish just to use a USB drive. It's a joke.

I've been a software engineer for 25 years, and it's easier to upload files to the internet and download to the pi rather than deal with this mounting un-mounting nightmare.

What is wrong with you people?

I recommend checking out how it's done on an operating system called 'Windows' that came out in the early '90's.

REPLY >

MATT on SEPTEMBER 7, 2016 8:36 PM

This is less to do with the Raspberry Pi and more to do with Linux. It is frustrating and as a Windows user I get what you are saying. However Windows is useless for the Raspberry Pi and useless for many of the hardware based projects the Pi is ideal for. Try making a battery powered wildlife camera (with or without USB stick storage) with Windows!

REPLY >

PIETERJAN on DECEMBER 18, 2016 7:36 PM

just use USB-mount

sudo apt-get -y install usbmount

REPLY >

MATT on DECEMBER 18, 2016 9:33 PM

Trouble with usbmount is that on the official page it says "The original author does not have enough time any more to actively maintain the USBmount package. It is therefore currently unmaintained." It's an option but was last updated in 2007.

REPLY >

COLIN on APRIL 20, 2017 9:41 AM

Does anyone know how I would auto mount all USB sticks to a specified folder rather than targeting one specific USB Stick?

REPLY >

MARK on MAY 20, 2017 2:12 PM

HI There,

thanks for the best instructions i could find to do this seemingly simple task.

I completed everything you advised but i still dont see my files in Subsonic, what do you think the problem could be?

REPLY >

DON DEGREGORI on JULY 7, 2017 2:44 AM

I followed along and was successful. Now, if I took the stick and put it in a Windows 10 system, would it work?

REPLY >

MATT on JULY 13, 2017 3:08 PM

It depends on the file system used. Windows can only read certain file systems.

DEDIV \

ABOUT

LEAVE A REPLY		
Your Comment		
Your Name		
Your Email		
Your Website		
		POST COMMENT
		POST COMMENT

RECENT POSTS

JULY 27, 2012

POPULAR POSTS

2 97

SEPTEMBER 3, 2017

Q 0

17/09/2017

Unofficial site devoted to the Raspberry Pi credit card sized computer offering tutorials, guides, resources, scripts and downloads. We hope to help everyone get the most out of their Pi by providing clear, simple articles on configuring, programming and operating it.

How To Mount A USB Flash Disk On The Raspberry Pi

16×2 LCD Module Control Using Python		IKEA Arcade Table Based On a Raspberry Pi Running RetroPie		
OCTOBER 20, 2013	Q ∤96	AUGUST 30, 2017	Q	
Analogue Sensors On The Pi Using An MCP3008	e Raspberry	Send Pushover Notification when MotionEyeOS Boots		
SEPTEMBER 19, 2014	2 83	AUGUST 9, 2017	Q	
Top 5 Reasons The Rasph Sucks	perry Pi	Controlling Energenie I with the Pi-mote Addor		
		-		

Entries RSS | Comments RSS

This site is not associated with the official Raspberrypi.org site or the Raspberry Pi Foundation. Raspberry Pi is a trademark of the Raspberry Pi Foundation.

Copyright © 2017 - All Rights Reserved - Matt Hawkins