SmartHub X200 User Manual

Welcome to the SmartHub X200, a compact home hub that connects your devices and lets you control them from one place.

This manual explains setup, charging, status lights, factory reset, firmware updates, troubleshooting and warranty.

Contents: 1. Box contents. 2. Charging. 3. Status lights. 4. Factory reset. 5. Firmware update. 6. Troubleshooting. 7. Warranty.

1. Box Contents

The SmartHub X200 package contains the SmartHub X200 unit, one USB-C power adapter, one USB-C charging cable, a quick start guide and a wall-mount bracket with two screws.

Check that all items are present before starting setup. If any item is missing, contact the store where you bought the device.

2. Charging the Battery

Connect the USB-C cable to the charging port on the back of the SmartHub X200 and plug the other end into the supplied power adapter.

A full charge takes about 2 hours. The battery indicator turns solid green when charging is complete.

A fully charged battery keeps the SmartHub running for up to 12 hours without mains power. Use only the supplied adapter for charging.

3. Status Lights

The LED on the front of the SmartHub shows the current state of the device.

Solid white: the device is on and connected. Slow pulsing blue: ready to pair with the app.

A blinking red light means the battery is below 10 percent. Connect the power adapter right away.

Solid red means an internal error. Restart the device, and if the light stays red, perform a factory reset.

4. Factory Reset

A factory reset erases all paired devices, saved Wi-Fi networks and custom settings, and returns the SmartHub to its original state.

To reset the device to factory settings, press and hold the reset button on the underside with a paperclip for 10 seconds, until the LED flashes white three times.

After the reset, set up the SmartHub again using the app.

5. Firmware Update

Firmware updates add new features and security fixes. Keep the SmartHub connected to Wi-Fi and plugged into power during the update.

To update the firmware, open the SmartHub app, go to Settings, tap Firmware, and then tap Update Now. The update takes about 5 minutes.

Do not unplug the device while the LED is pulsing green. The device restarts automatically when the update is finished.

6. Troubleshooting

Device will not turn on: make sure the power adapter is firmly connected and the wall outlet works. Hold the power button for 5 seconds. If it still does not turn on, charge it for 30 minutes and try again.

Device will not connect to Wi-Fi: move the SmartHub closer to your router and check that the Wi-Fi password is correct.

App cannot find the device: restart the SmartHub and make sure Bluetooth is enabled on your phone.

7. Warranty

The SmartHub X200 comes with a limited warranty of 2 years from the date of purchase. The warranty covers manufacturing defects in materials and workmanship.

The warranty does not cover damage from drops, unauthorized repairs or use of non-approved power adapters.

To make a warranty claim, keep your proof of purchase and contact customer support through the SmartHub app.