

### DEPARTURE PROCEDURE DESCRIPTION

 $\underline{\text{ALL AIRCRAFT}}: \text{Departure climb rate 470 ft/NM to 5 000 ft.}$ 

TAKE-OFF RWY 06L/R: Climb HDG 063° or Climb on assigned HDG by ATC......

TAKE-OFF RWY 24L/R: At least 35 ft AGL over DER, Climb HDG 243° or Climb on assigned HDG by ATC......

......Expect radar vector to intercept filed En-route fix or as assigned route by ATC. Maintain 5 400 ft or assigned altitude(flight level).

Expect filed altitude/flight level 10 minutes after departure.

LOST COMMUNICATIONS: If radio contact is not established with departure control prior to reaching 5 000 ft, Continue climb to 8 400 ft before turning to filed fix/Navaid and proceed filed route and altitude.

# **INTENTIONALLY**


**LEFT** 

**BLANK** 

STANDARD DEPARTURE CHART - INSTRUMENT(SID)

TRANSITION ALT 14 000 TRANSITION LVL FL 140 SACHEON DEP 135.4 347.3 SACHEON TWR 118.675 236.6 SACHEON/Sacheon(RKPS) RWY 06L/R SACHEON 1

Note: Departures under U.S. TERPS.



### **DEPARTURE ROUTE DESCRIPTION**

TAKE-OFF RWY 06L/R: Climb HDG  $064^{\circ}$  to SAC D5 thence,......

...... Climb to 8 000 ft via the following transition routes.

ANUBA Transition : Left turn HDG 310° to cross R 020 SAC and left turn HDG 240°

to R 283 SAC and R 283 SAC to ANUBA.

SAPDI Transition : Right turn HDG 130° to intercept R 093 SAC and R 093 SAC to SAPDI.

TOPAX Transition : Right turn HDG 190° to intercept R 142 SAC and R 142 SAC to TOPAX.

GOSBO Transition : Right turn HDG 250° to intercept R 204 SAC and R 204 SAC to GOSBO.

 $\underline{\text{ENGOT Transirion}} \quad : \text{Right turn HDG 190}^{\circ} \text{ to intercept R 138 SAC and R 138 SAC to ENGOT}.$ 

POVOR Transition : Right turn HDG 250° to intercept R 207 SAC and R 207 SAC to POVOR.

# **INTENTIONALLY**

**LEFT** 


**BLANK** 

STANDARD DEPARTURE CHART - INSTRUMENT(SID)

TRANSITION ALT 14 000 TRANSITION LVL FL 140

SACHEON DEP 135.4 347.3 SACHEON TWR 118.675 236.6 SACHEON/Sacheon(RKPS) RWY 24L/R SACHEON 2

Note : Departures under U.S. TERPS.



### **DEPARTURE ROUTE DESCRIPTION**

 $\underline{\text{TAKE-OFF RWY 24L/R}}: \text{Climb HDG 244}^\circ$  to SAC D5 thence,......

...... Climb to 8 000 ft via the following transition routes.

ANUBA Transition

GOSBO Transition

TOPAX Transition

SAPDI Transition

: Right turn HDG 330° to intercept R 283 SAC and R 283 SAC to ANUBA.

: Left turn HDG 150° to intercept R 204 SAC and R 204 SAC to GOSBO.

: Left turn HDG 050° to intercept R 142 SAC and R 142 SAC to TOPAX.

: Left turn HDG 050° to intercept R 093 SAC and R 093 SAC to SAPDI.

ENGOT Transition : Left turn HDG 050° to intercept R 138 SAC and R 138 SAC to ENGOT.

POVOR Transition : Left turn HDG 150° to intercept R 207 SAC and R 207 SAC to POVOR.

# **INTENTIONALLY**

**LEFT** 

**BLANK**