Pin	DB25 standard (not on Apollo 2)	Pin	DB25 Apollo *female* (Appendix 1 of the Manual)	to Pin	DB9 standard RS232	to Pin	DB25 standard RS232
2	TX		TX	2	RX	3	RX
3	RX		RX	3	TX	2	TX
4	RTS		DSR	4	DTR	20	DTR
5	CTS		GND	5	GND	7	GND
6	DSR		DTR	6	DSR	6	DSR
7	GND		CTS	7	RTS	4	RTS
8	DCD		RTS	8	CTS	5	CTS

http://bogpeople.com/networking/SerialComms/rs232pinouts.shtml

FEMALE connector **MALE connector**

