HomeHub French Door Refrigerator

Model series FR-560

User Manual and Care Guide

HomeHub support

Contents

1. Safety

2. Setup

3. Controls

4. Troubleshooting: not cooling

5. Service and warranty

1. Safety

• Read all instructions before using the appliance.

• Keep this manual for future reference and for any later owner.

• Installation must follow local plumbing and electrical codes.

• Do not allow children to operate the appliance unsupervised.

• Use only genuine Nordvik parts and accessories.

• Disconnect power before any cleaning near electrical parts.

Unplug before cleaning the condenser coils.

2. Setup

Do not allow children to operate the appliance unsupervised. Use only genuine Nordvik parts and accessories. Wipe up spills promptly to prevent staining and slipping. Keep this manual for future reference and for any later owner.

Disconnect power before any cleaning near electrical parts. Use only genuine Nordvik parts and accessories. Do not allow children to operate the appliance unsupervised. Wipe up spills promptly to prevent staining and slipping.

Keep this manual for future reference and for any later owner. Use only genuine Nordvik parts and accessories. Read all instructions before using the appliance. Do not allow children to operate the appliance unsupervised.

Leave 2 in. clearance behind and at the sides. Wait 4 hours after moving before plugging in.

3. Controls

Setting	Recommended
Fridge	37 F
Freezer	0 F

Use only genuine Nordvik parts and accessories. Check supply hoses for wear once a year. Keep this manual for future reference and for any later owner. Disconnect power before any cleaning near electrical parts.

Check supply hoses for wear once a year. Use only genuine Nordvik parts and accessories. Wipe up spills promptly to prevent staining and slipping. Do not allow children to operate the appliance unsupervised.

4. Troubleshooting: not cooling

If the refrigerator is not cooling, try these steps in order.

Step	Check	Action
1	Power	Confirm the plug is seated and the outlet works. Check the breaker.
2	Temperature setting	Set fridge to 37 F, freezer to 0 F. Wait 24 hours.
3	Door seals and airflow	Close doors fully; do not block vents; remove ice buildup.
4	Condenser coils	Unplug, vacuum the coils at the base or rear.
5	Condenser fan	Listen for the fan; if silent, call service.
6	Compressor	If the compressor does not run or clicks repeatedly, call service. Do not attempt repair.

Allow 24 hours after any change. Food safety: discard perishables above 40 F for more than 2 hours.

5. Service and warranty

The compressor and sealed system carry an extended warranty. See the warranty card and register your serial number.

Wipe up spills promptly to prevent staining and slipping. Disconnect power before any cleaning near electrical parts. Keep this manual for future reference and for any later owner. Check supply hoses for wear once a year.