
MCHOSE

AX5 V2 Wireless Mouse


Warm Reminder: The product images shown are for illustrative purposes only; the actual product shall prevail.

PRODUCT OVERVIEW



CONNECTION METHOD


For Charging / Wired Connection Use



•Connect the Type-C end of the standard USB cable to the corresponding port on the mouse, and the USB end to the corresponding port on the computer to start using.

•In 2.4G / wireless mode, plugging in the USB cable will switch the mouse to wired mode while charging it at the same time.

For 2.4G Connection Use




•Toggle the switch to [2.4G], then plug the USB end of the included USB cable into your computer's USB port to use.

•Manual pairing (factory default is already paired): Remove the USB receiver from the adapter, then press and hold the mouse [Left + Middle + Right buttons] simultaneously for about 5 seconds until the indicator flashes green rapidly, entering pairing mode. At this time, insert the USB receiver back into the adapter and place the mouse within 20 cm of the receiver. The connection is successful when the indicator light turns off.

For Wireless Connection Use

Press simultaneously for about 3 seconds



Switch to [B], search for and connect to the device named [MCHOSE AX5 V2].If the connection fails, press and hold the mouse [Left + Middle + Right buttons] simultaneously for about 3 seconds until the indicator flashes rapidly to enter pairing mode, then try connecting again.The connection is successful when the indicator light turns off.

DRIVER INTRODUCTION

M HUB Web : https://www.mchose.com.cn

Open the URL in your browser,

Click [Enter M HUB WEB] - [Allow Browser Access], then select the corresponding product model to connect.

M HUB Driver : https://www.maicong.cn

Open the URL in your browser,

Click [Driver] - [Download M HUB Driver]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.

INDICATOR LIGHT STATUS

01.DPI Adjustment

Single press the 【DPI Switch Button】 to cycle through six DPI levels, adjustable via the driver.

Level 1: Red Light **400DPI**


Level 2: Blue Light **800DPI**

Level 3: Green Light **1600DPI**

Level 4: Yellow Light **3200DPI**


Level 5: Cyan Light **6400DPI**

Level 6: Purple Light **42000DPI**



02.Battery Status Indicator

When the indicator light flashes red, please charge the mouse in time.



Indicator light flashing red:
Please charge in time.

Indicator light flashing orange:
Charging in progress.

Indicator light off:
Charging complete.

Note: This device has been tested and complies with the limits for Class B digital devices under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations.
This device generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception (which can be determined by turning the device off and on), we encourage the user to try one or more of the following measures to correct the interference:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the responsible party could void the user’ s authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

CHARGING INSTRUCTION

1. It is recommended to charge the mouse only via a computer USB port.
2. Avoid using substandard or non-compliant power adapters to charge the mouse.
3. Avoid using over-voltage or over-current power adapters for charging.
4. Keep the mouse away from high-temperature devices while charging.
5. Please turn off the power switch if the device will not be used for an extended period.

These charging instructions also apply to other rechargeable devices (keyboard/mouse/headphones/speakers, etc.).