
User's Manual


MCHOSE

GX87 V2 Fully Aluminum Custom Keyboard

Warm Reminder: The product images shown are for illustrative purposes only; the actual product shall prevail.

PRODUCT OVERVIEW





Win / Mac Systems:

FN + S = Win system; FN + A = Mac mode. In Mac mode, the Alt key functions as the Command key, and FN + F1 - F12 enables the normal input of F1 - F12.

In the Win system, when switching to Mac system mode, the Win key and the left - hand Alt key will be swapped, and F1 - F12 will function as multimedia keys.


Indicator Lights:

Win Indicator Light: The Win key - position light indicates the locked state of the Win key. When the Win key is locked, the light stays on, and the Win key cannot be used.

CONNECTION MODE


2.4G Connection:

•Slide the mode - change switch to 【2.4G】.
•Take out the receiver from the storage slot.
•Insert the receiver into the computer's USB port.
•Manual pairing (factory - default paired): Long - press 【FN + Q】 for 3 seconds until the indicator light flashes rapidly. Then insert the receiver into the computer's USB port. Once the connection is successful, the backlight effect will be restored.




Wired Connection:

•Slide the mode - change switch to the 【OFF】 mode.
•Insert the Type - C end of the USB cable into the corresponding port of the keyboard.
•Insert the USB end of the cable into the corresponding port of the computer to start using it.



Wireless Connection:

•Slide the mode - change switch to the 【B】 mode.
•Long - press 【FN + W】 to start pairing. The indicator light will flash rapidly during pairing.
•Press 【FN + W】, 【FN + E】, 【FN + R】 to switch devices.



Pairing name:
【MCHOSE GX87 V2 3.0】
【MCHOSE GX87 V2 5.0】

DRIVER INTRODUCTION

M HUB Web : https://www.mchose.com.cn

Open the URL in your browser,

Click [Enter M HUB WEB] - [Allow Browser Access], then select the corresponding product model to connect.


M HUB Driver : https://www.maicong.cn

Open the URL in your browser,

Click [Driver] - [Download M HUB Driver]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.

FN COMBINATION KEY



+

ESC	Long - press for 3s to restore default
=+	Backlight mode switch
-_	Backlight color switch
↑	Backlight brightness +
↓	Backlight brightness -
←	Backlight speed -
→	Backlight speed +
,<	Status indicator brightness +
.>	Status indicator brightness -
/?	Status indicator color switch
Right Shift	Status indicator lighting effect switch
Left Shift	Switch back to charging indication status
B	Press and hold to check battery level


FN COMBINATION KEY



+

Win system

Key	Multimedia combination function	Multimedia function (single press)
F1	Screen brightness -	F1
F2	Screen brightness +	F2
F3	Task View	F3
F4	File Explorer	F4
F5	Search	F5
F6	Screenshot	F6
F7	Previous Track	F7
F8	Play/Pause	F8
F9	Next Track	F9
F10	Mute	F10
F11	Volume -	F11
F12	Volume +	F12



+

Mac system

Key	Multimedia combination function	Multimedia function (single press)
F1	F1	Screen brightness -
F2	F2	Screen brightness +
F3	F3	Switch Window
F4	F4	Return to Desktop
F5	F5	Short-press for Search, Long-press for Siri
F6	F6	Screenshot
F7	F7	Previous Track
F8	F8	Play/Pause
F9	F9	Next Track
F10	F10	Mute
F11	F11	Volume -
F12	F12	Volume +

*The initial function of a single press on the 【F13】 key is 【Return to Desktop】.

POWER MANAGEMENT

1. Battery Level Check


•In 2.4G/wireless mode (when the USB is not plugged in), you can press FN + B to display the keyboard's battery level.
•When fully charged, all the number keys from 1 to 0 will light up green. As the battery is consumed, the number of green - lit keys gradually decreases. When the battery level is low, the keys will light up red.

2. Charging Method

•In any mode, connecting the keyboard to a computer via the provided data cable will charge the keyboard.
•During charging, the 【Status Indicator】 will display a running - light effect. When fully charged, the 【Status Indicator】 will stay lit green.

3. Sleep Function

•In wireless/2.4G mode, if there is no operation for one minute, the keyboard will automatically enter power - saving mode. Click any key to wake up the keyboard.



Note: This device has been tested and complies with the limits for Class B digital devices under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations.
This device generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation.
If this device does cause harmful interference to radio or television reception (which can be determined by turning the device off and on), we encourage the user to try one or more of the following measures to correct the interference:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the responsible party could void the user’ s authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

CHARGING INSTRUCTION

1.It is recommended to charge the keyboard only via the computer's USB port.
2.Do not use a fast - charging mobile phone charger to charge the keyboard.
3.Do not use substandard or non - compliant power adapters to charge the keyboard.
4.Do not use power adapters with over - voltage or over - current to charge the keyboard.
5.Keep away from high - temperature devices when charging.
6.Turn off the power switch when not in use for an extended period.

These charging instructions also apply to other rechargeable devices (keyboard/mouse/headphones/speakers, etc.).