
MCHOSE

Ace 68 *Air 2*
Magnetic Switch Gaming Keyboard

Warm Reminder: The product images shown are for illustrative purposes only; the actual product shall prevail.

PRODUCT OVERVIEW



DRIVER INTRODUCTION

M HUB Web : https://www.mchose.com.cn

Open the URL in your browser,

Click [Enter M HUB WEB] - [Allow Browser Access], then select the corresponding product model to connect.

M HUB Driver : https://www.maicong.cn

Open the URL in your browser,

Click [Driver] - [Download M HUB Driver]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.

FN COMBINATION KEY



+

O	Press and hold for 2 seconds to switch to Windows mode (default)	6 ^	F6
P	Press and hold for 2 seconds to switch to Mac mode	7 &	F7
1 !	F1	8 *	F8
2 @	F2	9 (	F9
3 #	F3	0)	F10
4 $	F4	¯_	F11
5 %	F5	= +	F12

FN COMBINATION KEY



+

Esc	·	C	Play/Pause
] }	Pause	V	Stop
[{	Print	B	Mute Volume
Ins	Home	N	Volume-
Del	End	M	Volume+
Z	Previous track	Win	Lock/Unlock Win Key
X	Next track	Space	Restore Default Settings (Long press for about 3 seconds)

FN COMBINATION KEY



+

Q	Light Box Light On/Off	Y	Switch Key Color
W	Switch Light Box Light Mode	U	Cycle Backlight Effects
E	Light Box Light Brightness Down	F	Backlight Brightness -
R	Light Box Light Brightness Up	G	Backlight Brightness +
A	Switch Light Box Light Color	H	Backlight Speed -
T	Turn Backlight Off / On	J	Backlight Speed +