
MCHOSE

Ace 68 GT
E-sports Hall Effect Magnetic Switch Keyboard

Warm Reminder: The product images shown are for illustrative purposes only; the actual product shall prevail.

PRODUCT OVERVIEW



DRIVER INTRODUCTION

M HUB Web : https://www.mchose.com.cn

Open the URL in your browser,

Click [Enter M HUB WEB] - [Allow Browser Access], then select the corresponding product model to connect.


M HUB Driver : https://www.maicong.cn

Open the URL in your browser,

Click [Driver] - [Download M HUB Driver]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.

FN COMBINATION KEY



+

O	Press and hold for 2 seconds to switch to Windows mode (default)	6 ^	F6
P	Press and hold for 2 seconds to switch to Mac mode	7 &	F7
1 !	F1	8 *	F8
2 @	F2	9 (	F9
3 #	F3	0)	F10
4 $	F4	-_	F11
5 %	F5	= +	F12


FN COMBINATION KEY



+

Esc	·	C	Play/Pause
] }	Pause	V	Stop
[{	Print	B	Mute
Ins	Home	N	Volume -
Del	End	M	Volume +
Z	Previous Track	Win	Lock/Unlock Win Key
X	Next Track	Spacebar	Restore Default Settings (Press and Hold for ~2s)

FN COMBINATION KEY



+

W	Switch Ambient Light Mode	U	Switch Lighting Effect
E	Ambient Light Brightness -	F	Lighting Brightness -
R	Ambient Light Brightness +	G	Lighting Brightness +
A	Switch Ambient Light Color	H	Lighting Speed -
T	Turn off / Turn on	J	Lighting Speed +
Y	Switch Key Color		