
MCHOSE

Mix 87
E-sports Hall Effect
Magnetic Switch Keyboard

Warm Reminder: The product images shown are for illustrative purposes only; the actual product shall prevail.

PRODUCT OVERVIEW



DRIVER INTRODUCTION

M HUB Web : https://www.mchose.com.cn

Open the URL in your browser,

Click [Enter M HUB WEB] - [Allow Browser Access], then select the corresponding product model to connect.

M HUB Driver : https://www.maicong.cn

Open the URL in your browser,


Click [Driver] - [Download M HUB Driver]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.

FN COMBINATION KEY


Fn +	O	P	D	F
	Win system	Mac system	Backlight mode switching	Backlight color switching
	G	Z	X	C
	Switch backlight speed	LOGO light brightness +	LOGO light brightness -	Switch LOGO light modes
	V	B	Win	
	Switch the color of the LOGO light	Switch the speed of the LOGO light	Lock/Unlock the Windows key	

FN COMBINATION KEY



+

Win system		
Key	**Multimedia combination function**	**Multimedia function (single press)**
F1	Screen brightness -	F1
F2	Screen brightness +	F2
F3	/	F3
F4	/	F4
F5	/	F5
F6	/	F6
F7	Last song	F7
F8	Play/Pause	F8
F9	Next song	F9
F10	Mute	F10
F11	Volume -	F11
F12	Volume +	F12



+

Mac system		
Key	**Multimedia combination function**	**Multimedia function (single press)**
F1	F1	Screen brightness -
F2	F2	Screen brightness +
F3	F3	/
F4	F4	/
F5	F5	/
F6	F6	/
F7	F7	Previous Track
F8	F8	Play/Pause
F9	F9	Next Track
F10	F10	Mute
F11	F11	Volume -
F12	F12	Volume +