
MCHOSE

G98 V3

CUSTOM MECHANICAL KEYBOARD

Warm Reminder: The product images shown are for illustrative purposes only; the actual product shall prevail.

PRODUCT OVERVIEW




Connection Modes

2.4G Connection:


- Slide the mode switch to [2.4G]
- Remove the USB receiver from the storage slot
- Plug the receiver into an available USB port on your computer

Note:
Press and hold [FN + ~] for about 3 seconds to re-pair the 2.4G connection. The status indicator will flash rapidly. Plug the receiver into your computer's USB port. The pairing is successful when the status indicator returns to its normal state (pre-paired by default).




Wired Connection:

- Slide the mode switch to [OFF] mode
- Plug the Type-C end of the USB cable into the corresponding port on the keyboard
- Plug the USB-A end of the cable into the corresponding port on your computer to use the keyboard



Wireless Connection:

- Slide the mode switch to the [B] mode
- Long press [FN+1!] to start pairing; the indicator light will flash rapidly during pairing
- Press [FN+1!], [FN+2@], [FN+3#] to switch between devices



■ DRIVER INTRODUCTION

M HUB Web : https://www.mchose.com.cn

Open the URL in your browser,

Click [Enter M HUB WEB] - [Allow Browser Access], then select the corresponding product model to connect.

M HUB Driver : https://www.maicong.cn

Open the URL in your browser,

Click [Driver] - [Download M HUB Driver]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.

■ FN COMBINATION KEY



O	Hold for approx. 2s to switch to Win system (Default)
P	Hold for approx. 2s to switch to Mac system
] }	Cycle through lighting control modes (Backlight, Indicator light)
[{	Switch lighting color
\ |	Switch lighting effect
Shift	Turn lighting On/Off (Right Shift)
↑	Increase brightness +

↓	Decrease brightness -
→	Increase lighting speed +
←	Decrease lighting speed -
B	Check battery level
WIN	Lock/Unlock WIN key
Esc	Hold for approx. 3s to restore default settings
Left Shift	Switch Charging Mode

FN MULTIMEDIA FUNCTION



+

Win system		
Key	**Multimedia combination function**	**Multimedia function (single press)**
F1	Decrease screen brightness -	F1
F2	Increase screen brightness +	F2
F3	Switch window	F3
F4	File Explorer	F4
F5	/	F5
F6	/	F6
F7	Previous track	F7
F8	Play/Pause	F8
F9	Next track	F9
F10	Mute	F10
F11	Decrease volume -	F11
F12	Increase volume +	F12


Mac system		
Key	**Multimedia combination function**	**Multimedia function (single press)**
F1	F1	Decrease screen brightness -
F2	F2	Increase screen brightness +
F3	F3	Switch window
F4	F4	Return to desktop
F5	F5	Short press for Search / Long press to call Siri
F6	F6	Screenshot
F7	F7	Previous track
F8	F8	Play/Pause
F9	F9	Next track
F10	F10	Mute
F11	F11	Decrease volume -
F12	F12	Increase volume +

■ Power Management

Battery Check

In 2.4G / Wireless mode (without USB connected), press FN + B to display the keyboard battery level. Release to resume lighting effects.

- When fully charged, keys [1! - 0)] will light up solid green.
- As the battery drains, the number of green-lit keys will gradually decrease.
- When keys [1! - 2@] light up red, it indicates low battery.



Charging Method

- The indicator light flashes red when the battery is low.
- In any mode, connecting the keyboard to a computer with the included data cable will charge the keyboard.
- While charging, press FN + Left Shift to switch to charging display mode. During charging, the indicator light flows with mixed colors from left to right.
- When fully charged, all indicator lights stay solid green for 10 seconds, then revert to the lighting effect used before charging.

Note: This device has been tested and complies with the limits for Class B digital devices under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations.
This device generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation.
If this device does cause harmful interference to radio or television reception (which can be determined by turning the device off and on), we encourage the user to try one or more of the following measures to correct the interference:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the responsible party could void the user’ s authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

CHARGING INSTRUCTION

1.It is recommended to charge the keyboard only via the computer's USB port.
2.Do not use a fast - charging mobile phone charger to charge the keyboard.
3.Do not use substandard or non - compliant power adapters to charge the keyboard.
4.Do not use power adapters with over - voltage or over - current to charge the keyboard.
5.Keep away from high - temperature devices when charging.
6.Turn off the power switch when not in use for an extended period.

These charging instructions also apply to other rechargeable devices (keyboard/mouse/headphones/speakers, etc.).