
MCHOSE

# Jet 75
# Hall Effect Magnetic Switch Keyboard

# PRODUCT OVERVIEW



# DRIVER INTRODUCTION

**M HUB Web :** https://www.mchose.com.cn

Open the URL in your browser,

Click [Enter M HUB WEB] - [Allow Browser Access], then select the corresponding product model to connect.

**M HUB Driver :** https://www.maicong.cn

Open the URL in your browser,

Click [Driver] - [Download M HUB Driver]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.

# FN COMBINATION KEY

| | | | | | |
|---|---|---|---|---|---|
| Fn + | O | P | Esc | A | S |
| | Win system | Mac system | Press and hold for 3 seconds to restore factory settings | Backlight brightness + | Backlight brightness - |
| | D | F | G | Z | X |
| | Backlight mode switching | Backlight color switching | Cycle through backlight speed adjustments | LOGO light brightness + | LOGO light brightness - |
| | C | V | B | Delete | Home |
| | Switch LOGO light modes | Switch LOGO light colors | Switch LOGO light speeds | Ins | End |

# FN COMBINATION KEY

| Key Position | F1 | F2 | F3 | F4 | F5 | F6 |
|---|---|---|---|---|---|---|
| Single Press | F1 | F2 | F3 | F4 | F5 | F6 |
| Fn Combination | Screen brightness - | Screen brightness + | / | / | / | / |
| Key Position | F7 | F8 | F9 | F10 | F11 | F12 |
| Single Press | F7 | F8 | F9 | F10 | F11 | F12 |
| Fn Combination | Last song | Pause/Play | Next song | Mute | Volume - | Volume + |

*Supports general keyboard functions of Windows; is compatible with standard key functions of MacOS, but special function keys are not supported.