
User's Manual

MCHOSE

K87S Custom mechanical keyboard

Warm Reminder: The product images shown are for illustrative purposes only; the actual product shall prevail.

PRODUCT OVERVIEW




1. Indicator Lights:
•CAPS Indicator Light: The CAPS key light indicates the Caps Lock status. It stays on when Caps Lock is enabled.
•Win Indicator Light: The Win key light indicates whether the Windows key is locked. It stays on when the Win key is locked, during which the key is disabled.

2.Win/Mac System Modes:
•FN + A = Windows mode; FN + S = Mac mode. In Mac mode, the Alt key functions as the Command key, and FN + F1–F12 inputs standard F1–F12 functions.
•In Windows mode, if switched to Mac mode, the Win and Left Alt keys will be swapped, and F1–F12 will serve as multimedia keys.

CONNECTION MODE


2.4G Connection:

•Toggle the mode switch to 【2.4G】
•Remove the receiver from the storage slot
•Plug the receiver into the computer's USB port
•Manual pairing (pre-paired by default):
Press and hold 【FN + `~】 until the indicator light flashes slowly. Then insert the receiver into the computer's USB port. The lighting will return to normal once connected successfully.




Wired Connection:

•Toggle the mode switch to 【OFF】 mode
•Plug the Type-C end of the USB cable into the corresponding port on the keyboard
•Plug the USB end of the cable into the computer's corresponding port to start using



Wireless Connection:

•Toggle the mode switch to 【B】 mode
•Press and hold 【FN + 1!】 to start pairing; the indicator light will flash slowly during pairing
•Press 【FN + 1!】, 【FN + 2@】, or 【FN + 3#】 to switch between devices



DRIVER INTRODUCTION

M HUB Web : https://www.mchose.com.cn

Open the URL in your browser,

Click [Enter M HUB WEB] - [Allow Browser Access], then select the corresponding product model to connect.


M HUB Driver : https://www.maicong.cn

Open the URL in your browser,

Click [Driver] - [Download M HUB Driver]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.


FN COMBINATION KEY



Right Shift	Toggle Keyboard Backlight
|	Switch Keyboard Light Mode
]}	Switch Backlight Color
▲	Backlight Brightness +
▼	Backlight Brightness -
►	Backlight Speed +
◄	Backlight Speed -
DEL	Switch Indicator Light Mode
INS	Switch Indicator Light Color
PGDN	Indicator Light Brightness -
PGUP	Indicator Light Brightness +

END	Indicator Light Speed -
HOME	Indicator Light Speed +
ESC	Hold 3s to Restore Factory Settings
A	Switch to Windows System
S	Switch to Mac System
~ (Hold for 3s)	2.4G Pairing
1 !	Switch Bluetooth Channel 1
2 @	Switch Bluetooth Channel 2
3 #	Switch Bluetooth Channel 3
B	Check Battery Level (In 2.4G/Wireless Mode)

FN COMBINATION KEY



+

Win system		
Key	**Multimedia combination function**	**Multimedia function (single press)**
F1	System brightness -	F1
F2	System brightness +	F2
F3	WIN+TAB	F3
F4	WIN+E	F4
F5		
F6		
F7	Previous track	F7
F8	Play / Pause	F8
F9	Next track	F9
F10	Mute	F10
F11	Volume -	F11
F12	Volume +	F12

Mac system		
Key	**Multimedia combination function**	**Multimedia function (single press)**
F1	F1	System brightness -
F2	F2	System brightness +
F3	F3	Window switch
F4	F4	Return to desktop
F5	F5	Search
F6	F6	Screenshot
F7	F7	Previous track
F8	F8	Play / Pause
F9	F9	Next track
F10	F10	Mute On/Off
F11	Return to desktop	Volume -
F12	F12	Volume +

POWER MANAGEMENT


1. Battery Level Check

In 2.4G/wireless mode (no USB inserted), press FN + B to display the keyboard’ s battery level: other backlights will turn off, and the lighting effect will restore when you release the keys.

•Full battery: Numpad keys [1! - 0)] light up green.

•As battery depletes: The number of green-lit keys decreases.

•Low battery: Numpad keys [1! - 3#] light up red.



2. Charging Method

•Low battery: Status indicator flashes red.

•Charge the keyboard by connecting it to a computer via the included cable (works in any mode).

Note: This device has been tested and complies with the limits for Class B digital devices under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations.
This device generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation.
If this device does cause harmful interference to radio or television reception (which can be determined by turning the device off and on), we encourage the user to try one or more of the following measures to correct the interference:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the responsible party could void the user’ s authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

CHARGING INSTRUCTION

1.It is recommended to charge the keyboard only via the computer's USB port.
2.Do not use a fast - charging mobile phone charger to charge the keyboard.
3.Do not use substandard or non - compliant power adapters to charge the keyboard.
4.Do not use power adapters with over - voltage or over - current to charge the keyboard.
5.Keep away from high - temperature devices when charging.
6.Turn off the power switch when not in use for an extended period.

These charging instructions also apply to other rechargeable devices (keyboard/mouse/headphones/speakers, etc.).