
User's Manual

R9 Dual Headband Lightweight Gaming Headset


Warm Reminder: The product images shown are for illustrative purposes only;the actual product shall prevail.


PRODUCT OVERVIEW



Status Indicator Light	·Bluetooth Pairing Mode: Red and blue LEDs flash alternately; Bluetooth Connected: Blue LED flashes slowly ·2.4G Pairing Mode: Red and green LEDs flash alternately; 2.4G Connected: Green LED flashes slowly ·Charging: Red LED stays solid; Fully Charged: Green LED stays solid ·Low Battery: Red LED flashes slowly
Power Button	Power On / Off: Long press for approx. 3s Switch Connection Mode: Double-click Voice Battery Report: Single-click
Mic Button	Mic On / Off: Single-click Answer / End Call: Double-click Reject Incoming Call: Long press for approx. 1.5s
Volume Roller	Volume Up: Scroll Up Volume Down: Scroll Down
Multi-function Key	Play / Pause: Single-click Audio Effect Switch: Double-click
Type-C Port	
Mic Indicator Light	Mic Enabled: Solid blue LED Mic Disabled: Blue LED off


2.4G Connection






*** Receiver Re-pairing: With the headset in 2.4G mode, long-press the Ⓖ key for 5 seconds until the indicator flashes white rapidly 3 times. Plug the USB receiver into your computer. A solid green indicator light on the receiver confirms successful 2.4G re-pairing.**
*** Keep the headset as close to the receiver as possible during manual binding.**

Bluetooth Connection



*** Pairing Name: MCHOSE R9**
*** Bluetooth Re-pairing: Power on the headset under Bluetooth Mode, long-press the Ⓖ key for 5 seconds until the indicator flashes white rapidly 3 times. The headset will re-enter Bluetooth pairing mode.**
(If no connection is established within 5 minutes, the headset will power off automatically.)

■ Sound Card Mode / Headset Charging



* When the headset is powered on, plug the data cable into the headset and connect it to a computer; the headset will automatically switch to Sound Card Mode.


* Double-tap the ⏻ button to cycle between 【Adapter Mode】 / 【Bluetooth Mode】 / 【Sound Card Mode】.

* Insert the Type-C end of the data cable into the headset port and the other end into your computer port to charge the headset.

* Low battery: Red indicator flashes slowly; Charging: Red indicator stays solid; Fully charged: Green indicator stays solid.

* Single-tap the ⏻ button to announce current battery level.

■ Headband Adjustmentc



* Press the【Adjustment Button】to achieve stepless headband adjustment. No need to remove the headset for quick adaptation to different head sizes.

■ DRIVER INTRODUCTION

M HUB Desktop driver : https://www.maicong.cn

Open the URL in your browser,

Click [Driver] - [Download M HUB Client]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.

MCHOSE APP: https://cdn.mchose.com.cn/doc/app.html

Open the URL or scan the QR code via your mobile browser to enter the APP download page.

Tap 【Download from App Store】 or 【Download Installation Package】 to proceed.

MCHOSE APP

Note: This device has been tested and complies with the limits for Class B digital devices under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations.

This device generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this device does cause harmful interference to radio or television reception (which can be determined by turning the device off and on), we encourage the user to try one or more of the following measures to correct the interference:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the responsible party could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

CHARGING INSTRUCTION

1.It is recommended to charge the headset only via a computer USB port.

2.Do not use power adapters with overvoltage or overcurrent to charge the headset.

3.Keep the headset away from high-temperature devices while charging.

4.Turn off the power switch when the headset is not in use for an extended period.

5.Do not use inferior or non-standard power adapters to charge the headset.

These charging instructions also apply to other rechargeable devices (keyboard/mouse/headphones/speakers, etc.).