
User's Manual

MCHOSE

V9 Pro 2 GAMING HEADSET


Warm Reminder: The product images shown are for illustrative purposes only;the actual product shall prevail.


PRODUCT OVERVIEW



Status Indicator LED	·Bluetooth Pairing: Red & Blue LEDs flash alternately; Bluetooth Connected: Blue LED slow-flash ·2.4G Pairing: Red & Green LEDs flash alternately; 2.4G Connected: Green LED slow-flash ·Charging: Red LED solid on; Fully Charged: Green LED solid on ·Low Battery: Red LED slow-flash
Power Button	Power On / Off: Long press for approx. 3 seconds
Volume Scroll Wheel	Volume +: Scroll Up Volume -: Scroll Down
Multi-function Button	Play / Pause: Single Click Switch Connection Mode: Double Clic Switch Sound Effect: Long press for approx. 1.5sk
Mic Button	Mic On / Off: Single Click Answer / End Call: Double Click Reject Incoming Call: Long press for approx. 1.5s
Type-C Port	
Mic Indicator LED	Microphone Enabled: Blue LED solid on Microphone Muted: Blue LED off

2.4G CONNECTION






* Re-pair the Receiver: With the headset in 2.4G Mode, long press the [Power Key] and [Mic Key] simultaneously until the white indicator flashes quickly 3 times. Plug the USB receiver into your computer.
A steady green light on the receiver indicates successful 2.4G re-pairing.

* When performing manual binding, place the headset as close to the receiver as possible.


Bluetooth Connection



* Pairing Name: MCHOSE V9 Pro 2

* Bluetooth Re-pairing: With the headset powered on in Bluetooth Mode, long press the [Power Key] and [Mic Key] simultaneously for 5 seconds until the white indicator flashes quickly 3 times.
The headset will enter Bluetooth pairing mode again.
(If no connection is established within 5 minutes, the headset will power off automatically.)

Sound Card Mode / Headset Charging



* When the headset is powered on, plug the data cable into the headset and connect it to the computer; the headset will automatically switch to Sound Card Mode.
* Double-tap the Ⓖ key to cycle between [Adapter Mode] / [Bluetooth Mode] / [Sound Card Mode].
* Plug the Type-C end of the data cable into the matching port on the headset, and plug the other end into the computer's port to charge the headset.
* Low Battery: Red indicator slow flash; Charging: Red indicator solid on; Fully Charged: Green indicator solid on.

■ DRIVER INTRODUCTION

M HUB Desktop driver : https://www.maicong.cn

Open the URL in your browser,

Click [Driver] - [Download M HUB Client]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.

Note: This device has been tested and complies with the limits for Class B digital devices under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations.
This device generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation.
If this device does cause harmful interference to radio or television reception (which can be determined by turning the device off and on), we encourage the user to try one or more of the following measures to correct the interference:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the responsible party could void the user’ s authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

CHARGING INSTRUCTION

1.It is recommended to charge the headset only via a computer USB port.
2.Do not use power adapters with overvoltage or overcurrent to charge the headset.
3.Keep the headset away from high-temperature devices while charging.
4.Turn off the power switch when the headset is not in use for an extended period.
5.Do not use inferior or non-standard power adapters to charge the headset.

These charging instructions also apply to other rechargeable devices (keyboard/mouse/headphones/speakers, etc.).