
MCHOSE

X9 GAMING HEADSET

Warm Reminder: The product images shown are for illustrative purposes only;the actual product shall prevail.

PRODUCT OVERVIEW



Microphone button
Microphone On/Off: Single-click
Answer/End a Call: Double-click
Reject an Incoming Call: Long-press for approximately 1.5 seconds

Multifunctional button
Pause/Play: Single-click
Connection Mode Switch: Double-click
Sound Effect Switch: Long-press for approximately 2 seconds

Volume scroll wheel
Volume Up: Scroll upwards
Volume Down: Scroll downwards


Type-C jack

Power indicator light
When pairing via Bluetooth:
The red and blue lights flash alternately.
When Bluetooth is connected:
The blue light flashes slowly.
When pairing in 2.4G mode:
The red and green lights flash alternately.
When 2.4G is connected:
The green light flashes slowly.
When charging:
The red light stays on constantly.
When fully charged:
The green light stays on constantly.

Microphone indicator light
When the microphone is turned on: The blue light stays on constantly.
When the microphone is turned off: The blue light goes out.

Power button
Power On/Off: Long-press for approximately 3 seconds.
RGB Lighting On/Off: Single-click.

2.4G CONNECTION



* Receiver binding (bound by factory default): When the earphone is in 2.4G mode, press and hold the [Power button] and [Microphone button] until the white light of the indicator light flashes 3 times, plug the USB receiver into the computer, and the green indicator light of the receiver is always on, that is, the 2.4G re-pairing is successful.

* When manually binding, place the earphones as close to the receiver as possible.

DRIVER INTRODUCTION


M HUB Desktop driver : https://www.maicong.cn

Open the URL in your browser,

Click [Driver] - [Download M HUB Client]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.


BT WIRELESS



Warm Reminder: After the earphones are disconnected over a distance, when the earphones return to the connection range again, they will automatically reconnect to the device. If no device is reconnected within 5 minutes, the earphones will automatically shut down.

Bluetooth restores to factory settings: Turn off the earphone in Bluetooth mode, and then press ⏻ and hold for 8 seconds until the white light of the indicator light flashes 3 times, that is, the recovery is successful, and the connection can be re-paired. (If the original device has a connection record, please delete it manually)

SOUND CARD MODE




1. When the earphone is turned on, insert the data cable into the earphone and connect it to the computer, and the earphone will automatically switch to the sound card mode.

2. You can double-click ⏻ to switch the [Adapter Mode]/[Bluetooth Mode] /[Sound Card Mode] cycle.

3. In 2.4G and Bluetooth modes, plug in the charging cable and play while charging.

HEADPHONE CHARGING



Low Battery:
Red indicator light flashes slowly

Charging:
Red indicator light stays on

Fully Charged:
Blue indicator light stays on

Note: This device has been tested and complies with the limits for Class B digital devices as set forth in Part 15 ofthe FCC Rules. These limits are designed to provide reasonable protection against harmful interference in aresidential installation. This device generates, uses, and can radiate radio freguency energy, and if not installed ancused in accordance with the instructions, may cause harmful interference to radio communications. However, thereis no guarantee that interfer-ence will not occur in a particular installation.

If this device does cause harmful interference to radio or television reception (which can be determined by turningthe device off and on), we encourage the user to try one or more of the following measures to correct theinterference:

· Reorient or relocate the receiving antenna.

· Increase the separation between the equipment and the receiver.

· Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

· Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the responsible party for compliance could void the user's authority to operate the equipment..

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.