

MCHOSE


K7 Ultra Flagship E - sports Mouse

Warm Reminder: The product images shown are for illustrative purposes only; the actual product shall prevail.


PRODUCT OVERVIEW








Charging / Wired Connection Usage



Plug the USB end of the included USB cable into the corresponding port on your computer, and the Type-C end into the matching port on the mouse. The mouse will then switch to wired mode and start charging.

2.4G connection




Switch the power button to the 【2.4G】 mode, plug the USB end of the included USB cable into the corresponding port on your computer, and the Type-C end into the matching port on the magnetic wireless charging dock.

*Manual Pairing (Pre-paired at Factory): Press and hold the left, middle, and right mouse buttons simultaneously for about 5 seconds until the indicator light flashes green rapidly to enter pairing mode. Then plug the Type-C end of the included USB cable (connected to your computer) into the matching port on the magnetic wireless charging dock, and bring the mouse close to the dock (within 20cm). The indicator light will turn off once the connection is successful.

***When the 1K receiver and 8K receiver are connected to the computer simultaneously, the receiver plugged into the computer first will be prioritized for pairing.**

Magnetic Wireless Charging Dock Charging




Plug the USB end of the included USB cable into the corresponding port on your computer, and the Type-C end into the matching port on the magnetic wireless charging dock. Place the mouse directly on the dock— the indicator light will stay solid red to enter charging mode, and turn solid green once fully charged.

*When wired charging and wireless charging are performed simultaneously, wired charging is the default.

Wireless Connection

Press simultaneously for about 5 seconds



Switch the power button to 【B】 mode, search for the pairing name 【MCHOSE K7 Ultra】 and click to connect. If the connection fails, press and hold the left, middle, and right mouse buttons simultaneously for about 5 seconds until the indicator light flashes rapidly to enter pairing mode, then try connecting again. The indicator light will turn off once the connection is successful.

■ DRIVER INTRODUCTION

M HUB Web : https://www.mchose.com.cn

Open the URL in your browser,

Click [Enter M HUB WEB] - [Allow Browser Access], then select the corresponding product model to connect.

M HUB Driver : https://www.maicong.cn

Open the URL in your browser,

Click [Driver] - [Download M HUB Driver]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.

DPI Adjustment

Level 1: Red Light 400DPI


Level 2: Blue Light 800DPI

Level 3: Green Light 1600DPI


Level 4: Yellow Light 3200DPI

Level 5: Cyan Light 6400DPI

Level 6: Purple Light 42000DPI



Battery Status Indicator



The red indicator light is flashing:
Please charge immediately

Indicator light red and solid:
Charging

Indicator light green and solid:
Charging completed

Note: This device has been tested and complies with the limits for Class B digital devices under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations.
This device generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception (which can be determined by turning the device off and on), we encourage the user to try one or more of the following measures to correct the interference:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the responsible party could void the user’ s authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

CHARGING INSTRUCTION

1. It is recommended to charge the mouse only via a computer USB port.
2. Avoid using substandard or non-compliant power adapters to charge the mouse.
3. Avoid using over-voltage or over-current power adapters for charging.
4. Keep the mouse away from high-temperature devices while charging.
5. Please turn off the power switch if the device will not be used for an extended period.

These charging instructions also apply to other rechargeable devices (keyboard/mouse/headphones/speakers, etc.).