
MCHOSE

Ace 68 series
Professional - grade e - sports
Hall Effect Magnetic Switch Keyboard


Warm Reminder: The product images shown are for illustrative purposes only; the actual product shall prevail.

PRODUCT OVERVIEW

Ace 68



Ace 68 Air



DRIVER INTRODUCTION

M HUB Web : https://www.mchose.com.cn

Open the URL in your browser,

Click [Enter M HUB WEB] - [Allow Browser Access], then select the corresponding product model to connect.

M HUB Driver : https://www.maicong.cn


Open the URL in your browser,

Click [Driver] - [Download M HUB Driver]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.

LIGHTING FUNCTION


Ace 68



+

T	Turn on/off the light
Y	Switch light effect color
U	Cycle through light effects
F	Light brightness -
G	Light brightness +
H	Light speed -
J	Light speed +

Ace 68 Air




+

Q	Turn on/off light box lights
W	Switch light box lighting modes
E	Light box light brightness -
R	Light box light brightness +
A	Switch light box light colors
T	Turn off/on keyboard LED lights
Y	Switch backlight colors
U	Switch backlight effects
F	Backlight brightness -
G	Backlight brightness +
H	Backlight speed -
J	Backlight speed +

FN COMBINATION KEY


Ace 68



+

ESC	·
1!	F1
2@	F2
3#	F3
4$	F4
5%	F5
6^	F6
7&	F7
8*	F8
9(	F9
0)	F10
-_	F11
=+	F12

Ace 68 Air




+

ESC	~
1!	F1
2@	F2
3#	F3
4$	F4
5%	F5
6^	F6
7&	F7
8*	F8
9(	F9
0)	F10
-_	F11
=+	F12

FN COMBINATION KEY


Ace 68



+

O	Win system
P	Mac system
]}	Pause
[{	Print
Ins	Home
Del	End
Z	Last song
X	Next song
C	Pause/Play
V	Stop
B	Mute
N	Volume -
M	Volume +
Win	Lock/Unlock the Windows key
Space	Restore default

Ace 68 Air



+

O	Win system(default)
P	Mac system
]}	Pause
[{	Print
Ins	Home
Del	End
Z	Last song
X	Next song
C	Pause/Play
V	Stop
B	Mute
N	Volume -
M	Volume +
Win	Lock/Unlock the Windows key
Space	Restore default