
MCHOSE

Ace 60 ISO
Magnetic Switch Keyboard

Tips: The pictures in this manual are schematic diagrams and may differ from the actualproduct. Please refer to the actual product.

PRODUCT OVERVIEW



DRIVER INTRODUCTION

M HUB Web : https://www.mchose.com.cn

Open the URL in your browser,

Click [Enter M HUB WEB] - [Allow Browser Access], then select the corresponding product model to connect.


M HUB Driver : https://www.maicong.cn

Open the URL in your browser,

Click [Driver] - [Download M HUB Driver]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.

FN COMBINATION KEY




+

Ech	~
1 &	F1
2 é ~	F2
3 " #	F3
4 ' {	F4
5 ([	F5
6 - ¦	F6
7 è `	F7
8 _ \	F8
9 ç ^	F9
0 à @	F10
°)]	F11
+ = }	F12

/ :	Switch Backlight Color
¨ ^	Backlight Brightness -
£ $ ¤	Backlight Brightness +
M	Backlight Speed -
% ù	Backlight Speed +
µ *	Switch Light Mode

FN COMBINATION KEY



+

Y	PRT SCR
U	Scrlk
I	PAUSE
H	INS
J	HOME
K	PageUp
Backspace	Delete
▪ ;	PageDown
? '	End
W	Previous Song
X	Pause/Play

C	Next Song
V	Volume +
B	Volume -
N	Mute
§ !	↑
Fn	↓
AltGr	←
Right CTRL	→
Left CTRL	Number or F1 Function Key Area Swap
Space	Restore Defaults