User's Manual

MCHOSE | 凡人


God 60

FANREN Animation Co-branded Magnetic Switch Keyboard


Warm Reminder: The product images shown are for illustrative purposes only; the actual product shall prevail.

PRODUCT OVERVIEW

Volume Scroll Wheel




Ring Ambient Light



Top Ambient Light

Top Ambient Light



RT Trigger

Type-C port

DRIVER INTRODUCTION

M HUB Web : https://www.mchose.com.cn

Open the URL in your browser,

Click [Enter M HUB WEB] - [Allow Browser Access], then select the corresponding product model to connect.

M HUB Driver : https://www.maicong.cn

Open the URL in your browser,

Click [Driver] - [Download M HUB Driver]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.

FN COMBINATION KEY



+

O	Hold for 2 seconds to switch to Windows mode (Default)
P	Hold for 2 seconds to switch to macOS mode
Esc	`
1 !	F1
2 @	F2
3 #	F3
4 $	F4
5 %	F5
6 ^	F6
7 &	F7
8 *	F8
9 (	F9
0)	F10
-_	F11
= +	F12

FN COMBINATION KEY



+

/ ?	↑	⟵	Delete
	↓	U	Home
ALT (Left)	←	I	Pgup
CTRL (Right)	→	H	Insert
Z	Previous Track	J	End
C	Next Track	K	Pgdn
X	Play / Pause	WIN	Lock / Unlock Win Key
CTRL (Left)	Swap Numpad & F Function Keys	SPACE	Restore Factory Settings (Long press for approx. 3s)

FN COMBINATION KEY



+

SHIFT	Turn On / Off Lighting (Right Shift)	’ ”	Light Brightness +
\ |	Switch Light Effect Mode	; :	Light Brightness -
] }	Cycle Light Control Modes	. >	Light Speed +
[{	Switch Light Effect Color	, <	Light Speed -