
MCHOSE

K99 V3 MECHANICAL KEYBOARD

Warm Reminder: The product images shown are for illustrative purposes only; the actual product shall prevail.

■ PRODUCT OVERVIEW




CONNECTION MODE

2.4G wireless connection:


- Toggle the Mode Switch to the [2.4G] position.
- Remove the USB receiver from the storage slot, or press to eject it.
- Plug the receiver into a USB port on your computer.

Note: Press and hold [FN+~] for about 3 seconds to re-pair 2.4G.
The Status Indicator Light will flash rapidly. Once the receiver is plugged into the computer's USB port and the indicator light returns to its normal state, pairing is successful (pre-paired by default at factory).




Wired connection:

- Toggle the Mode Switch to the [OFF] mode.
- Plug the Type-C end of the USB cable into the corresponding port on the keyboard.
- Plug the USB end of the cable into the corresponding port on your computer, and it's ready to use.



Wireless connection:

- Toggle the Mode Switch to the [B] mode.
- Press and hold [FN+1!] to start pairing; the indicator light will flash rapidly during pairing.
- Press [FN+1!], [FN+2@], or [FN+3#] to switch between devices.



■ DRIVER INTRODUCTION

M HUB Web : https://www.mchose.com.cn

Open the URL in your browser,

Click [Enter M HUB WEB] - [Allow Browser Access], then select the corresponding product model to connect.


M HUB Driver : https://www.maicong.cn

Open the URL in your browser,

Click [Driver] - [Download M HUB Driver]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.


■ FN COMBINATION KEY



+

B	Check Battery Level (in 2.4G/Wireless Mode)	▶	Increase Backlight Speed
Win	Lock/Unlock Win Key	◀	Decrease Backlight Speed
}]	Increase Ambient Light Brightness	▲	Increase Backlight Brightness
{ [	Decrease Ambient Light Brightness	▼	Decrease Backlight Brightness
’ ”	Increase Ambient Light Speed	DEL	Switch Backlight Mode
: ;	Decrease Ambient Light Speed	- _	Switch Backlight Color
\ |	Switch Ambient Light Color Effects	+ =	Switch Status Indicator Light Color
S	Press and hold for ~2s to switch to Mac System	HOME	Switch Status Indicator Light Mode
A	Press and hold for ~2s to switch to Win System (Default)	8	Increase Status Indicator Light Brightness
Shift	Turn Backlight On/Off (Right Shift)	2	Decrease Status Indicator Light Brightness
Esc	Restore Factory Settings (Press and hold for ~3s)	6	Increase Status Indicator Light Speed
END	Switch Ambient Light Effect Modes	4	Decrease Status Indicator Light Speed

■ Multimedia Functions



+


Win system		
Key	**Multimedia combination function**	**Multimedia function (single press)**
F1	Decrease System Brightness	F1
F2	Increase System Brightness	F2
F3	Switch Windows	F3
F4	File Explorer	F4
F5	F5	F5
F6	F6	F6
F7	Previous Track	F7
F8	Play/Pause	F8
F9	Next Track	F9
F10	Mute	F10
F11	Decrease Volume	F11
F12	Increase Volume	F12

Mac system		
Key	**Multimedia combination function**	**Multimedia function (single press)**
F1	F1	Decrease System Brightness
F2	F2	Increase System Brightness
F3	F3	Switch Windows
F4	F4	Return to Desktop
F5	F5	(Search; Press and hold for Siri)
F6	F6	Screenshot
F7	F7	Previous Track
F8	F8	Play/Pause
F9	F9	Next Track
F10	F10	Mute
F11	F11	Decrease Volume
F12	F12	Increase Volume

■ Power Management

1. Check Battery Level

Press and hold FN+B to check the battery level (in 2.4G/Wireless Mode). The 10 number keys (1~0) on the keyboard will light up; the number of lit keys indicates the remaining battery. As the battery depletes, the green lights gradually decrease. When the number keys [1! – 3#] turn red, it means the



2. Charging Method

•Charge the keyboard by connecting it to a computer via the included cable (works in any mode).
•The indicators will cycle through mixed colors from top to bottom. When fully charged, all indicators will stay green for 10 seconds, then revert to the lighting effect before charging.

Note: This device has been tested and complies with the limits for Class B digital devices under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations.
This device generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation.
If this device does cause harmful interference to radio or television reception (which can be determined by turning the device off and on), we encourage the user to try one or more of the following measures to correct the interference:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the responsible party could void the user’ s authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

CHARGING INSTRUCTION

1.It is recommended to charge the keyboard only via the computer's USB port.
2.Do not use a fast - charging mobile phone charger to charge the keyboard.
3.Do not use substandard or non - compliant power adapters to charge the keyboard.
4.Do not use power adapters with over - voltage or over - current to charge the keyboard.
5.Keep away from high - temperature devices when charging.
6.Turn off the power switch when not in use for an extended period.

These charging instructions also apply to other rechargeable devices (keyboard/mouse/headphones/speakers, etc.).