
MCHOSE


S9 Pro GAMING HEADSET

Warm Reminder: The product images shown are for illustrative purposes only;the actual product shall prevail.

PRODUCT OVERVIEW



POWER ON/OFF



Indicator Light stays on for 1 second

Indicator Light stays on for 1 second

Power On: Press and hold for 3 seconds

Power Off: Press and hold for 3 seconds

DRIVER INTRODUCTION


M HUB Desktop driver : https://www.maicong.cn


Open the URL in your browser,

Click [Driver] - [Download M HUB Client]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.

2.4G CONNECTION






* To use the Type-C interface, you need to pull it out from the side of the adapter to plug it into the device. If you use the USB interface to connect the device, you need to plug the Type-C interface back into the side of the adapter before you can use it.
* 2.4G manual pairing (paired by factory default): When the earphone is in 2.4G mode, press and hold the [Power button] and [Microphone button] until the white light of the indicator light flashes 3 times, plug the USB transmitter into the computer, and the green indicator light of the transmitter is always on, that is, the 2.4G re-pairing is successful.
* When pairing manually, place the earphones as close to the transmitter as possible.

WIRELESS CONNECT


Pairing Name：MCHOSE S9 PRO




Warm Reminder: After the earphones are disconnected over a distance, when the earphones return to the connection range again, they will automatically reconnect to the device. If no device is reconnected within 5 minutes, the earphones will automatically shut down.

WIRED CONNECTION

When the headset is powered on and a 3.5mm audio cable is plugged in, the headset will automatically power off and enter the wired mode. In wired mode, only the volume knob of the headset is functional, and all other buttons are non - functional.



KEY FUNCTION



Answer: double click

Hang up: double click

Reject: Long press 1.5S

Turn the microphone on/off: click

Play/Pause: Click

Wireless/2.4G mode switching: double click

Game/Music Mode Switch: Long press 2S

Power on: Long press 2.5S


Shutdown: Long press 3S

Light On/Off: Click

CHARGING FUNCTION

Charging indicator light: normally on

Fully charged indicator light: off



· When you hear [insufficient power, please charge in time] or [power indicator light] red light flashing every 1.5 seconds, please charge the earphones in time.

Note: This device has been tested and complies with the limits for Class B digital devices as set forth in Part 15 ofthe FCC Rules. These limits are designed to provide reasonable protection against harmful interference in aresidential installation. This device generates, uses, and can radiate radio freguency energy, and if not installed ancused in accordance with the instructions, may cause harmful interference to radio communications. However, thereis no guarantee that interfer-ence will not occur in a particular installation.

If this device does cause harmful interference to radio or television reception (which can be determined by turningthe device off and on), we encourage the user to try one or more of the following measures to correct theinterference:

· Reorient or relocate the receiving antenna.

· Increase the separation between the equipment and the receiver.

· Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

· Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the responsible party for compliance could void the user's authority to operate the equipment..

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.