
User's Manual

MCHOSE

V9 *Turbo* GAMING HEADSET


Warm Reminder: The product images shown are for illustrative purposes only;the actual product shall prevail.


PRODUCT OVERVIEW



Volume Knob	Volume +: Turn upwards Volume -: Turn downwards
Status Indicator Lights	Bluetooth Pairing: Red and blue lights flash alternately Bluetooth Connected: Blue light flashes slowly 2.4G Pairing: Red and green lights flash alternately 2.4G Connected: Green light flashes slowly Charging: Red light stays on Fully Charged: Green light stays on Low Battery: Red light flashes slowly
Power Button	Power On/Off: Press and hold for approximately 3 seconds
Multifunction Button	Pause/Play: Single press Connection Mode Switch: Double press Sound Effect Switch: Press and hold for approximately 1.5 seconds
Microphone Button	Microphone On/Off: Single press Answer/End Call: Double press Reject Incoming Call: Press and hold for approximately 1.5 seconds
Type-C Port	
Microphone Indicator Light	Microphone On: Blue light stays on Microphone Off: Blue light turns off

2.4G CONNECTION






* Receiver Pairing (Paired by default at factory): With the headset in 2.4G mode, press and hold the Power Button and Microphone Button until the white indicator light flashes rapidly three times. Insert the USB receiver into your computer. Once the receiver's green indicator light stays on, the 2.4G re-pairing is successful.

* During manual pairing, place the headset as close to the receiver as possible.


BLUETOOTH CONNECTION



Pairing Name: MCHOSE V9 Turbo

* Re-enter Bluetooth Pairing:With the headset powered on and in Bluetooth mode, press and hold the Power Button and Microphone Button for 5 seconds until the white indicator light flashes rapidly three times. This will re-enter Bluetooth pairing mode. (If no connection is made within 5 minutes, the headset will automatically turn off.)


SOUND CARD MODE




1. With the headset powered on, connect it to your computer using the data cable. The headset will automatically switch to Sound Card Mode.

2. Double-press the Ⓖ to cycle through Adapter Mode / Bluetooth Mode / Sound Card Mode.

HEADSET CHARGING







1. Connect one end of the Type-C data cable to the headset's corresponding port, and the other end to your computer's port to charge the headset.
2. Low Battery: Red indicator light flashes slowly. Charging: Red indicator light stays on. Fully Charged: Green indicator light stays on

DRIVER INTRODUCTION

M HUB Desktop driver : https://www.maicong.cn

Open the URL in your browser,

Click [Driver] - [Download M HUB Client]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.

Note: This device has been tested and complies with the limits for Class B digital devices under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations.
This device generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation.
If this device does cause harmful interference to radio or television reception (which can be determined by turning the device off and on), we encourage the user to try one or more of the following measures to correct the interference:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the responsible party could void the user’ s authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

CHARGING INSTRUCTION

1.It is recommended to charge the headset only via a computer USB port.
2.Do not use power adapters with overvoltage or overcurrent to charge the headset.
3.Keep the headset away from high-temperature devices while charging.
4.Turn off the power switch when the headset is not in use for an extended period.
5.Do not use inferior or non-standard power adapters to charge the headset.

These charging instructions also apply to other rechargeable devices (keyboard/mouse/headphones/speakers, etc.).