
MCHOSE

ZERO 75 series
Hall Effect Magnetic Switch Keyboard



1.The left position is for WORK.
2.The right position is for GAME.

·In GAME mode, the keyboard backlight is turned off, the Logo indicator light stays red, and the Win key is locked.

·In WORK standard mode, the keyboard backlight and Logo light display normal lighting effects. This is the default mode.

•DRIVER INTRODUCTION

M HUB Web : https://www.mchose.com.cn

Open the URL in your browser,

Click [Enter M HUB WEB] - [Allow Browser Access], then select the corresponding product model to connect.

M HUB Driver : https://www.maicong.cn

Open the URL in your browser,

Click [Driver] - [Download M HUB Driver]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.

•FN COMBINATION KEY

Fn +	Esc	A	S	D	F
	Press and hold for 3 seconds to restore factory settings	Backlight brightness +	Backlight brightness -	Backlight mode switching	Backlight color switching
	G	Z	X	C	V
	Cycle through backlight speed adjustments	LOGO light brightness +	LOGO light brightness -	Switch LOGO light modes	Switch LOGO light colors
	B	Delete	Home		
	Switch LOGO light speeds	Ins	End		

FN + O = Windows system (default); FN + P = Mac system.

Friendly reminder: System switching is a new feature added in the ZERO 75X version.
This feature is not available in other versions.

• Instructions for Fn combination keys (Multimedia functions)

Key Position	F1	F2	F3	F4	F5	F6
Single Press	F1	F2	F3	F4	F5	F6
Fn Combination	Screen brightness -	Screen brightness +	/	/	/	/
Key Position	F7	F8	F9	F10	F11	F12
Single Press	F7	F8	F9	F10	F11	F12
Fn Combination	Last song	Pause/Play	Next song	Mute	Volume -	Volume +

*Supports general keyboard functions of Windows; is compatible with standard key functions of MacOS, but special function keys are not supported.