
MCHOSE

Ace 75
Magnetic Switch Gaming Keyboard

Warm Reminder: The product images shown are for illustrative purposes only; the actual product shall prevail.

PRODUCT OVERVIEW



DRIVER INTRODUCTION

M HUB Web : https://www.mchose.com.cn

Open the URL in your browser,

Click [Enter M HUB WEB] - [Allow Browser Access], then select the corresponding product model to connect.


M HUB Driver : https://www.maicong.cn

Open the URL in your browser,

Click [Driver] - [Download M HUB Driver]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.

FN COMBINATION KEY



+

O	Hold for 2 seconds to switch to Windows mode (Default)
P	Hold for 2 seconds to switch to macOS mode
] }	Cycle through lighting modes
[{	Switch lighting effect color
\ |	Switch lighting effect mode
SHIFT	Turn lighting on/off (Right Shift)

↑	Lighting Brightness +
↓	Lighting Brightness -
→	Lighting Speed +
←	Lighting Speed -
WIN	Lock/Unlock Windows Key
ESC	Restore Factory Settings (Hold for approx. 3s)

FN COMBINATION KEY



+

Win system			Mac system		
Key	**Multimedia Combination Functions**	**Multimedia Functions (Single Press)**	**Key**	**Multimedia Combination Functions**	**Multimedia Functions (Single Press)**
F1	Screen Brightness -	F1	F1	F1	Screen Brightness -
F2	Screen Brightness +	F2	F2	F2	Screen Brightness +
F3	Switch Window	F3	F3	F3	Switch Application Windows
F4	File Explorer	F4	F4	F4	Show Desktop
F5	/	F5	F5	F5	Short press: Search / Long press: Activate Siri
F6	/	F6	F6	F6	Screenshot
F7	Previous Track	F7	F7	F7	Previous Track
F8	Play/Pause	F8	F8	F8	Play/Pause
F9	Next Track	F9	F9	F9	Next Track
F10	Mute	F10	F10	F10	Mute
F11	Volume -	F11	F11	F11	Volume -
F12	Volume +	F12	F12	F12	Volume +