User's Manual

MCHOSE


G3 V3 Lightweight Wireless Mouse

Warm Reminder: The product images shown are for illustrative purposes only; the actual product shall prevail.

PRODUCT OVERVIEW

Status Indicator Light


- Fast flashing green light: 2.4G pairing in progress
- Fast flashing blue light: Bluetooth pairing in progress
- Fast flashing red light: Low battery
- Steady red light: Charging
- Steady green light: Fully charged



Type-C port

DPI Indicator Light

DPI Switch Button



2.4G Mode

Wired Mode


Wireless Mode

USB Receiver

■ Connection Methods

2.4G Connection


•Slide the mode switch to [2.4G]
•Take the USB receiver out of the storage slot
•Plug the receiver into a USB port on your computer
•Manual pairing (Pre-paired at factory): Press the Left, Middle and Right mouse buttons simultaneously for about 3 seconds until the indicator light flashes rapidly to enter pairing mode. Plug the USB receiver into the computer USB port, place the mouse within 20cm of the receiver. The indicator light will turn off once the connection succeeds.



Charging / Wired Connection

• Plug the Type-C end of the included USB cable into the corresponding port on the mouse, and plug the USB end into the matching port of your computer to start using.


• When in 2.4G / wireless mode, plugging in the USB cable will automatically switch the mouse to wired mode and charge the mouse simultaneously.



Wireless Connection

• Slide the switch to [B], search for the device with the matching pairing name and connect. If the connection fails, press the Left, Middle and Right mouse buttons simultaneously for about 3 seconds until the indicator flashes rapidly to enter pairing mode, then reconnect. The indicator will turn off once connected successfully.

Pairing Name: MCHOSE G3 V3



■ DRIVER INTRODUCTION

M HUB Web : https://www.mchose.com.cn

Open the URL in your browser,

Click [Enter M HUB WEB] - [Allow Browser Access], then select the corresponding product model to connect.

M HUB Driver : https://www.maicong.cn

Open the URL in your browser,

Click [Driver] - [Download M HUB Driver]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.

DPI Adjustment

Level 1: Red Light 400DPI


Level 2: Blue Light 800DPI

Level 3: Green Light 1600DPI


Level 4: Cyan Light 3200DPI

Level 5: Yellow Light 6400DPI

Level 6: Purple Light 12000DPI



Battery Status Indication



The red indicator light is flashing:
Please charge immediately

Indicator light red and solid:
Charging

Indicator light green and solid:
Charging completed

Note: This device has been tested and complies with the limits for Class B digital devices under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations.
This device generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception (which can be determined by turning the device off and on), we encourage the user to try one or more of the following measures to correct the interference:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the responsible party could void the user’s authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

⚠ CHARGING INSTRUCTION

1. It is recommended to charge the mouse only via a computer USB port.
2. Avoid using substandard or non-compliant power adapters to charge the mouse.
3. Avoid using over-voltage or over-current power adapters for charging.
4. Keep the mouse away from high-temperature devices while charging.
5. Please turn off the power switch if the device will not be used for an extended period.

These charging instructions also apply to other rechargeable devices (keyboard/mouse/headphones/speakers, etc.).