

MCHOSE

Ace 60 ISO
Magnetic Switch Keyboard

Tips: The pictures in this manual are schematic diagrams and may differ from the actualproduct. Please refer to the actual product.

PRODUCT OVERVIEW





DRIVER INTRODUCTION

M HUB Web : https://www.mchose.com.cn

Open the URL in your browser,

Click [Enter M HUB WEB] - [Allow Browser Access], then select the corresponding product model to connect.


M HUB Driver : https://www.maicong.cn

Open the URL in your browser,

Click [Driver] - [Download M HUB Driver]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.

FN COMBINATION KEY




+

ESC	~
1!	F1
2”@	F2
3#£	F3
4¤$	F4
5%	F5
6 &	F6
7/{	F7
8([	F8
9)]	F9
0=}	F10
+?\	F11
`|´	F12

. :	Switch Backlight Color
å	Backlight Brightness -
^¨~	Backlight Brightness +
ö Ø Æ	Backlight Speed -
Ä Æ Ø	Backlight Speed +
´ *	Switch Light Mode

FN COMBINATION KEY



+

Y	PRT SCR
U	Scrlk
I	PAUSE
H	INS
J	HOME
K	PageUp
Backspace	Delete
, ;	PageDown
M µ	End
Z	Previous Song
X	Pause/Play

C	Next Song
V	Volume +
B	Volume -
N	Mute
⁻_	↑
E	↓
Alt Gr	←
Right CTRL	→
Left CTRL	Number or F1 Function Key Area Swap
Space	Restore Defaults