MCHOSE

A5 V3 *Ultra* + Wireless Mouse

Warm Reminder: The product images shown are for illustrative purposes only; the actual product shall prevail.

PRODUCT OVERVIEW

Status Indicator Light


Green light flashing rapidly:
2.4G pairing in progress

Blue light flashing rapidly:
Wireless pairing in progress

Red light flashing rapidly:
Low battery

Red light constantly on:
Charging


Green light constantly on:
Charging completed



Type-C Port

DPI
Indicator
Light

DPI
Switch
Button




2.4G Mode

Wired Mode

Wireless Mode

Magnetic
Contact Surface

Type-C Port




Ambient light

USB port


Magnetic
contact surface

Charging / Wired connection use



Connect the included USB cable: plug the USB end into the corresponding port on your computer, and the Type-C end into the corresponding port on your mouse. The mouse will then switch to wired mode and begin charging.


Magnetic wireless charging base charging



Connect the included USB cable: insert the USB end into the corresponding port on your computer, and the Type-C end into the corresponding port on the magnetic wireless charging dock. Place the mouse on the magnetic wireless charging dock. A steady red light indicates the mouse is charging, and a steady green light means it is fully charged.

*When both wired and wireless charging are active simultaneously, wired charging takes priority by default.

2.4G Connection




Connection Method 1 (Recommended):Use the data cable included with this product. Insert one end into your computer's USB 2.0/3.0 port ①, and the Type-C end into the Type-C port ② on the magnetic wireless charging dock. Insert the receiver ③ into the USB-A port ② of the magnetic wireless charging dock. Place the dock with the receiver on a desktop, and ensure the distance between the receiver and the mouse is within 30 cm.

Connection Method 2:Insert the receiver ③ directly into your computer's USB 2.0/3.0 port ①.

*Magnetic Wireless Charging Dock: Designed to ensure long-distance signal transmission without attenuation and improve connection stability.

*2.4G Receiver: Comes pre-installed in the magnetic wireless charging dock by default.

Wireless Connection



Set the power switch to [B]. Press and hold the left, middle, and right mouse buttons simultaneously for approximately 5 seconds until the indicator light flashes blue rapidly, indicating the mouse is in pairing mode. Search for the pairing name [MCHOSE A5 V3 Ultra+] and connect. The indicator light will turn off once the connection is successful.

■ DRIVER INTRODUCTION

M HUB Web : https://www.mchose.com.cn

Open the URL in your browser,

Click [Enter M HUB WEB] - [Allow Browser Access], then select the corresponding product model to connect.

M HUB Driver : https://www.maicong.cn

Open the URL in your browser,

Click [Driver] - [Download M HUB Driver]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.

DPI ADJUSTMENT

Level 1: Red Light 400 DPI


Level 2: Blue Light 800 DPI

Level 3: Green Light 1600 DPI

Level 4: Yellow Light 3200 DPI

Level 5: Cyan Light 6400 DPI

Level 6: Purple Light 42000 DPI



The 6th-stage DPI of the 3955 version is 50000.


BATTERY STATUS INDICATOR

Status Indicator Light

Red light flashing rapidly: Low battery.

Red light constantly on: Charging.

Green light constantly on: Charging completed.



Note: This device has been tested and complies with the limits for Class B digital devices under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations.
This device generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception (which can be determined by turning the device off and on), we encourage the user to try one or more of the following measures to correct the interference:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the responsible party could void the user’ s authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

CHARGING INSTRUCTION

1. It is recommended to charge the mouse only via a computer USB port.
2. Avoid using substandard or non-compliant power adapters to charge the mouse.
3. Avoid using over-voltage or over-current power adapters for charging.
4. Keep the mouse away from high-temperature devices while charging.
5. Please turn off the power switch if the device will not be used for an extended period.

These charging instructions also apply to other rechargeable devices (keyboard/mouse/headphones/speakers, etc.).