MCHOSE


R7
Lightweight Ergonomic Mouse


Warm Reminder: The product images shown are for illustrative purposes only; the actual product shall prevail.

PRODUCT OVERVIEW

Status Indicator Light

- Green light flashing rapidly: 2.4G pairing in progress
- Blue light flashing rapidly: Wireless pairing in progress
- Red light flashing rapidly: Low battery
- Red light constantly on: Charging
- Green light constantly on: Charging completed





DPI Indicator Light

DPI Switch Button

Type-C Port

2.4G Mode

Wired Mode

Wireless Mode


USB Receiver
(Place inside the cover)

Connection Methods

2.4G Connection:

• Connection Method 1 (Recommended): Plug the included data cable into your computer's USB2.0/3.0 port ①. Insert the Type-C end of the data cable into the Type-C port ② of the adapter. Plug the receiver ③ into the USB-A port of the adapter. Place the adapter-mounted receiver on your desktop, and keep the distance between the receiver and the mouse within 30cm.


• Connection Method 2: Plug the receiver ③ directly into your computer's USB2.0/3.0 port ① for use.



Charging / Wired Connection:

• Plug the Type-C end of the bundled USB cable into the matching port on the mouse, and insert the standard USB connector into your computer's port for operation.


• After the USB cable gets connected, the mouse automatically switches to Wired Mode and begins charging concurrently.



Wireless Connection:

• Toggle the switch to position [B], locate and connect to the device named 【MCHOSE R7 Ultra】. If pairing fails, press the mouse's Left, Middle and Right buttons simultaneously for roughly 5 seconds until the indicator flashes rapidly to re-enter pairing mode and retry connection. The indicator will power off once pairing succeeds.

Press simultaneously for about 5 seconds



• R7 Ultra Pairing Name: 【MCHOSE R7 Ultra】

■ DRIVER INTRODUCTION

M HUB Web： https://www.mchose.com.cn

Open the URL in your browser,

Click [Enter M HUB WEB] - [Allow Browser Access], then select the corresponding product model to connect.

M HUB Driver： https://www.maicong.cn

Open the URL in your browser,

Click [Driver] - [Download M HUB Driver]

*The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.

DPI ADJUSTMENT

Level 1: Red Light 400 DPI


Level 2: Blue Light 800 DPI

Level 3: Green Light 1600 DPI

Level 4: Yellow Light 3200 DPI

Level 5: Cyan Light 6400 DPI

Level 6: Purple Light 50000 DPI




BATTERY STATUS INDICATOR

Status Indicator

Red light flashing rapidly:
Low battery.

Red light constantly on:
Charging.

Green light constantly on:
Charging completed.



Note: This device has been tested and complies with the limits for Class B digital devices under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations.
This device generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.
However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception (which can be determined by turning the device off and on), we encourage the user to try one or more of the following measures to correct the interference:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the responsible party could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference.
(2) This device must accept any interference received, including interference that may cause undesired operation.

⚠ CHARGING INSTRUCTION

1. It is recommended to charge the mouse only via a computer USB port.
2. Avoid using substandard or non-compliant power adapters to charge the mouse.
3. Avoid using over-voltage or over-current power adapters for charging.
4. Keep the mouse away from high-temperature devices while charging.
5. Please turn off the power switch if the device will not be used for an extended period.

These charging instructions also apply to other rechargeable devices (keyboard/mouse/headphones/speakers, etc.).