MCHOSE

G9/ G9 Pro Wireless &
G9 Wired Gaming Headset

Warm Reminder: The product images shown are for illustrative purposes only;the actual product shall prevail.


Product Overview

G9/ G9 Pro Wireless



Microphone Button	Microphone On/Off: Single press Answer/End Call: Double press Reject Call: Press and hold for 1.5 seconds
Indicator Light	Wireless Waiting for Connection: Red and blue lights flashing alternately 2.4G Waiting for Connection: Red and green lights flashing alternately Charging: Red light stays on Fully Charged: Blue light stays on
Power Button	Power On: Press and hold for 3 seconds; Power Off: Press and hold for 3 seconds Clear Pairing record: Press and hold for 10 seconds RGB Lighting On/Off: Single press
G Key	Mode Switch(Wireless /2.4G/Sound Card):Double press Sound Effect Switch(Music/Game 1/Game2): Press and hold for 2 seconds Play/Pause: Single press
Volume Wheel	Slide upward for Volume +; Slide downward for Volume-

G9 Wired




Lighting On/Off	Turn on lighting: Slide upward Turn off lighting: Slide downward
Volume Adjustment	Volume +: Slide upward Volume -: Slide downward Mute: Single press
Microphone Indicator Light	Microphone On: Blue light on Microphone Off: Red light on
Microphone Switch	On/Off: Single press

■ Driver Installation

Visit the official website: www.mchose.store. Click on [Drivers & Firmwaresl. Enter the G9 downloadpage, select the installation package corresponding to your model version, and click to download.Note:The G9 Wireless Edition does not support drivers.

2.4G Connection

G9/ G9 Pro Wireless



Receiver Pairing (Factory default paired): in 2.4G mode, press and hold the [Power Buttonj and llicrophone Button] until theindicator ioht flashes white three times. insert the USB receiver into the computer. and when the oreen indicator liaht on thereceiver stays on, the 2.4G re-pairing is successful.

Driver Introduction

M HUB Desktop driver : https://www.maicong.cn

Open the URL in your browser,


Click [Driver] - [Download M HUB Client]

*The G9 wireless version does not support the driver.
The M HUB client driver currently only supports Windows 10 and above operating systems; Windows 7 and macOS operating systems are not supported for now.


Wireless Connection

G9/ G9 Pro Wireless

MCHOSE G9 Wireless Pairing Name: MCHOSE G9
MCHOSE G9 Pro Wireless Pairing Name: MCHOSE G9 Pro



Note: The headset disconnects when out of range and automatically reconnects when the device isback in range. If no device reconnects within 5 minutes, the headset will automatically turn off.



1. 1. When the headset is powered on, insert the cable into the headset and connect it to thecomputer. The headset will automatically switch to sound card mode.
2. You can double press the iG Key] to cycle through [Adapter Model/[Wireless Mode]/ [SoundCard Model.
3. In 2.4G and Wireless modes, you can insert the charging cable to charge while playing.



Low Battery: Red indicator light flashes

Charging: Red indicator light stays on

Fully Charged: Blue indicator light stays

Note: This device has been tested and complies with the limits for Class B digital devices as set forth in Part 15 ofthe FCC Rules. These limits are designed to provide reasonable protection against harmful interference in aresidential installation. This device generates, uses, and can radiate radio freguency energy, and if not installed ancused in accordance with the instructions, may cause harmful interference to radio communications. However, thereis no guarantee that interfer-ence will not occur in a particular installation.

If this device does cause harmful interference to radio or television reception (which can be determined by turningthe device off and on), we encourage the user to try one or more of the following measures to correct theinterference:

· Reorient or relocate the receiving antenna.

· Increase the separation between the equipment and the receiver.

· Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

· Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the responsible party for compliance could void the user's authority to operate the equipment..

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.