























































































External module provides USB charging: PWR must be ON to charge. Carrier has no charger.
Unused GPIO and power-switch throw have explicit no-connects. Diode pad 1 is cathode.
Switch pin 1 -> column; pin 2 -> diode anode; cathode -> row. Right half is ZMK central.

by @roshbhatia

Sheet: /

File: crysknife_left.kicad_sch

Title: crysknife left

Size: A3	Date:	**Rev: 1.0.0**
KiCad E.D.A. 10.0.6		Id: 1/1