S3
C0 1
outer_top_SW
MX hotswap

S6
C1 1
pinky_top_SW
MX hotswap

S9
C2 1
ring_top_SW
MX hotswap

S12
C3 1
middle_top_SW
MX hotswap

S15
C4 1
index_top_SW
MX hotswap

S18
C5 1
inner_top_SW
MX hotswap

D3
R0 1
outer_top_SW
1N4148W (1=K, 2=A)

D6
R0 1
pinky_top_SW
1N4148W (1=K, 2=A)

D9
R0 1
ring_top_SW
1N4148W (1=K, 2=A)

D12
R0 1
middle_top_SW
1N4148W (1=K, 2=A)

D15
R0 1
index_top_SW
1N4148W (1=K, 2=A)

D18
R0 1
inner_top_SW
1N4148W (1=K, 2=A)

S2
C0 1
outer_home_SW
MX hotswap

S5
C1 1
pinky_home_SW
MX hotswap

S8
C2 1
ring_home_SW
MX hotswap

S11
C3 1
middle_home_SW
MX hotswap

S14
C4 1
index_home_SW
MX hotswap

S17
C5 1
inner_home_SW
MX hotswap

D2
R1 1
outer_home_SW
1N4148W (1=K, 2=A)

D5
R1 1
pinky_home_SW
1N4148W (1=K, 2=A)

D8
R1 1
ring_home_SW
1N4148W (1=K, 2=A)

D11
R1 1
middle_home_SW
1N4148W (1=K, 2=A)

D14
R1 1
index_home_SW
1N4148W (1=K, 2=A)

D17
R1 1
inner_home_SW
1N4148W (1=K, 2=A)

S1
C0 1
outer_bottom_SW
MX hotswap

S4
C1 1
pinky_bottom_SW
MX hotswap

S7
C2 1
ring_bottom_SW
MX hotswap

S10
C3 1
middle_bottom_SW
MX hotswap

S13
C4 1
index_bottom_SW
MX hotswap

S16
C5 1
inner_bottom_SW
MX hotswap

D1
R2 1
outer_bottom_SW
1N4148W (1=K, 2=A)

D4
R2 1
pinky_bottom_SW
1N4148W (1=K, 2=A)

D7
R2 1
ring_bottom_SW
1N4148W (1=K, 2=A)

D10
R2 1
middle_bottom_SW
1N4148W (1=K, 2=A)

D13
R2 1
index_bottom_SW
1N4148W (1=K, 2=A)

D16
R2 1
inner_bottom_SW
1N4148W (1=K, 2=A)

S19
C3 1
near_thumb_SW
MX hotswap

S20
C4 1
mid_home_SW
MX hotswap

S21
C5 1
far_home_SW
MX hotswap

D19
R3 1
near_thumb_SW
1N4148W (1=K, 2=A)

D20
R3 1
mid_home_SW
1N4148W (1=K, 2=A)

D21
R3 1
far_home_SW
1N4148W (1=K, 2=A)

MCU1A
24
23
GND 22
GND 21
20
19
18
R0 17
R1 16
R2 15
R3 14
13
315-43-112-41-003000

MCU1B
RAW 1
GND 2
RST 3
VCC 4
C0 5
C1 6
C2 7
C3 8
C4 9
C5 10
11
12
315-43-112-41-003000

U1
RAW 1
GND 2
RST 3
VCC 4
C0 5
C1 6
C2 7
C3 8
C4 9
C5 10
11
12
13
R3 14
R2 15
R1 16
R0 17
18
19
20
23
24
GND 21
GND 22
RAW/BAT+
GND
RST
3V3_OUT
C0
C1
C2
C3
C4
C5
unused_GPIO
unused_GPIO
unused_GPIO
R3
R2
R1
R0
unused_GPIO
unused_GPIO
unused_GPIO
unused_GPIO
unused_GPIO
GND
GND
nicenano V2 external module

PWR1
BAT_P1 1
RAW 2
3
SSSS811101

RST1
GND 1
RST 2
GND 3
RST 4
EVQPUC02K

JST1
GND 1
BAT_P2 2
PH2: 1=GND, 2=BAT+

#FLG01
RAW 1
external supply

#FLG02
GND 1
external supply

External module provides USB charging: PWR must be ON to charge. Carrier has no charger.
Unused GPIO and power-switch throw have explicit no-connects. Diode pad 1 is cathode.
Switch pin 1 -> column; pin 2 -> diode anode; cathode -> row. Right half is ZMK central.

by @roshbhatia
Sheet: /
File: fridakeys_left.kicad_sch
Title: fridakeys left
Size: A3 | Date: | Rev: 1.0.0
KiCad E.D.A. 10.0.6 | Id: 1/1