


Model	Year	MG	SG	Illustration	Restrictions	Update	14:33	18.11.2005	PORSCHE	PET	PORSCHE
944	85	8	04	804-10		194					



Pos	Part Number	Name	Remarks	Qty	Model
		installation parts door glass power windows			
1	477 837 385	window guide		4	
2	477 837 469 A	sealing outer	/L	1	
(2)	477 837 470 A	sealing outer	/R	1	
3	477 837 471 A	seal inner		2	
4	477 837 479 A	window guide		2	
5	477 837 493 A	window guide	/L	1	
(5)	477 837 494 A	window guide	/R	1	
6	477 837 441 A	power windows	/L	1	
(6)	477 837 442 A	power windows	/R	1	
7	171 837 485	clamp		10	
8	477 837 589	guide rail		2	
9	999 217 029 02	hexagon-head bolt M 6 X 10 self-locking		12	
10	N 011 652 1	washer A 7 X 12		12	
11	321 837 581	window crank		2	
		01C black			
		90V brown			
12	111 837 595 A	desk pad		2	
		01C black			
		90V brown			
13	477 837 391 C	cross-arm power window	/L	1	
(13)	477 837 392 C	cross-arm power window	/R	1	
14	477 959 123 A	engine and transmission	/L	1	
(14)	477 959 124 A	engine and transmission	/R	1	

Model	Year	MG	SG	Illustration	Restrictions	Update				
944	85	8	04	804-10		194	14:33	18.11.2005	PORSCHE	PET PORSCHE

Pos	Part Number	Name	Remarks	Qty	Model	Pos	Part Number	Name	Remarks	Qty	Model
15	N 014 228 4	countersunk-head screw AM 6 X 12		6		-	N 017 121 5	safety fuse 25 A		1	
15A	477 837 397	stop upper	/L	1				- - - E N D - - -			
15B	477 837 398	stop	/R	1							
15A	477 837 397	stop lower	/R	1							
15B	477 837 398	stop	/L	1							
16	477 867 185 A	mounting piece		1							
	1DB	black									
	4RB	brown									
17	477 867 187 A	mounting piece		1							
	1DB	black									
	4RB	brown									
18	477 867 189	spring clamp		4							
19	477 959 622	tip switch		3							
	01C	black									
	89S	brown									
		harness for power window									
-	477 971 160 A	harness dashboard	/LL -83	1							
-	944 612 031 00	harness dashboard	/LL 84-	1							
-	945 612 031 00	harness dashboard	/RL -83	1							
-	945 612 031 00	harness dashboard	/RL 84-	1							
-	477 971 161	harness dashboard		1							
-	477 971 162	harness passenger's door		1							
-	321 919 505	relay	-83	1							
-	944 615 112 01	relay	84-	1							