


Model	Year	MG	SG	Illustration	Restrictions	UPD	21:06	31.01.2010		PET	
944	1985	8	01	801-15		248	USA / CANADA				



Pos	Part Number	Description	Remark	Qty	Model
		side section			
(1)	931 503 601 03	side section	/L	1	
(1)	931 503 602 03	side section	/R	1	
(2)	931 503 901 01	side section	/L	1	
(2)	931 503 902 01	side section	/R	1	
3	944 503 611 00	door sill	/L	1	
(3)	944 503 612 00	door sill	/R	1	
4	931 503 517 00	roof frame	/L	1	
(4)	931 503 518 00	roof frame	/R	1	
5	931 503 411 00	hinge pillar	/L	1	
(5)	931 503 412 00	hinge pillar	/R	1	
6	944 503 068 00	pot tank filler neck		1	
7	477 809 375 A	bracket for light	/L	1	
(7)	477 809 376 A	bracket for light	/R	1	
8	477 809 445	reinforcement	/L	1	
(8)	477 809 446	reinforcement	/R	1	
9	477 809 585	filler plate	/L	1	
(9)	477 809 586	filler plate	/R	1	
10	477 809 617	retaining bracket lid boot floor lining	/L	1	
(10)	477 809 618	retaining bracket	/R	1	
11	477 809 653	mounting plate		4	
12	477 809 655	hinge reinforcement		4	
13	477 809 625	reinforcement		2	
14	944 503 097 00	reinforcement	/L	1	
(14)	944 503 098 00	reinforcement	/R	1	
15	928 504 355 02	gasket		4	
16	999 015 005 07	half-round screw		4	

Model	Year	MG	SG	Illustration	Restrictions	UPD	21:06	31.01.2010	PORSCHE PET PORSCHE		
944	1985	8	01	801-15		248	USA / CANADA				

Pos	Part Number	Description	Remark	Qty	Model	Pos	Part Number	Description	Remark	Qty	Model
17	477 809 393 A	hinge pillar inner use also: POS.17A	/L /LL 84-	1		26	477 809 397	centre pillar inner	/L	1	
(17)	477 809 394 A	hinge pillar	/R	1		(26)	477 809 398	centre pillar	/R	1	
17A	944 502 373 00	mounting switch rear lid release	84-	1		27	944 502 049 00	reinforcement inner	/L	1	
18	477 809 433	separator		2		(27)	944 502 050 00	reinforcement	/R	1	
19	944 502 901 00	side section inner	/L -83	1		28	477 809 427	closing element	/L	1	
19	944 502 901 01	side section inner	/L 84-	1		(28)	477 809 428	closing element	/R	1	
(19)	944 502 902 00	side section inner with expansion tank	/R -83	1		29	944 502 439 00	reinforcement	/L	1	
(19)	944 502 902 01	side section inner	/R 84-	1		(29)	477 809 440	reinforcement	/R	1	
20	931 502 387 01	corner plate	/L	1		30	931 504 095 00	flap F >>94EN4 66276		1	
(20)	931 502 388 01	corner plate	/R	1		30	944 504 095 00	flap F 94EN4 66277>>		1	
21	944 501 043 00	wheel housing inner	/L	1		31	477 853 403	desk pad		X	
(21)	944 501 044 00	wheel housing	/R	1		32	N 012 222 4	spring washer A 5		2	
22	931 502 411 01	wheel housing outer	/L	1		33	900 146 003 02	oval-head screw M5 X 10		2	
(22)	931 502 412 01	wheel housing	/R	1		34	931 504 397 00	stop rubber F >>94EN4 66276		1	
23	944 502 025 00	side section inner	/L/H	1		34	944 504 397 00	stop F 94EN4 66277>>		1	
(23)	944 502 026 00	side section	/R	1		35	944 555 275 00	filler piece	/L -83	1	
24	803 803 583	drain bush		X		(35)	944 555 275 01	filler piece	/L 84-	1	
(24)	021 119 569	rubber sleeve		X	M650	(35)	944 555 276 00	filler piece	/R	1	
25	477 809 037	separator	/L	1							
(25)	477 809 037	separator	/L	1	M650						
(25)	477 809 038	separator	/R	1							
(25) A	477 809 038	separator	/R	1	M650						