

## Catalina P2 Command and Options Summary

| Command<br>(1) | C<br>sources<br>(1 +) | Propeller<br>Hardware<br>Version<br>(1) | C<br>library<br>(<= 1) | Maths<br>library<br>(<= 1) | Other<br>libraries<br>(0 +) | Propeller<br>Base<br>Platform<br>(<= 1) | Memory<br>Model<br>(<= 1) | Cache<br>Option<br>(<= 1) | Human/Machine<br>Interface and<br>Graphics Option<br>(0 +) | Clock<br>Frequency<br>Options<br>(<= 1) | Miscellaneous<br>Options<br>(0 +) |
|----------------|-----------------------|-----------------------------------------|------------------------|----------------------------|-----------------------------|-----------------------------------------|---------------------------|---------------------------|------------------------------------------------------------|-----------------------------------------|-----------------------------------|
|                |                       | -                                       |                        |                            |                             |                                         |                           | -                         | -                                                          | -                                       |                                   |
|                |                       |                                         |                        |                            |                             |                                         |                           |                           | -C TTY                                                     |                                         | -C NO_SCREEN                      |
|                |                       |                                         |                        |                            |                             |                                         |                           |                           | -C SIMPLE                                                  |                                         | -C NO_MOUSE                       |
|                |                       |                                         |                        |                            |                             |                                         |                           |                           | -C VGA                                                     |                                         | -C NO_KEYBOARD                    |
|                |                       |                                         |                        |                            |                             |                                         |                           |                           | -C LORES_VGA                                               |                                         | -C CR_ON_LF                       |
|                |                       |                                         |                        |                            | -ltiny                      |                                         |                           | -C CACHED_1K              | -C HIRES_VGA                                               |                                         | -C NO_CR_TO_LF                    |
|                |                       |                                         | -lc                    | -lm                        | -lserial2                   | -C P2_EVAL                              | -C NATIVE                 | -C CACHED_2K              | -C VGA_640                                                 | -C MHZ_200                              | -C NON_ANSI_HMI                   |
| catalina       | program.c             | -p2                                     | -lci                   | -lma                       | -lserial8                   | -C P2D2                                 | -C COMPACT                | -C CACHED_4K              | -C VGA_800                                                 | -C MHZ_220                              | -C NO_LUT                         |
|                |                       |                                         | -lcix                  | -lmb                       | -lthreads                   | -C P2_EDGE                              | -C TINY                   | -C CACHED_8K              | -C VGA_1024                                                | -C MHZ_260                              | -C NO_FIFO                        |
|                |                       |                                         | -lcx                   | -lmc                       | -lint                       | -C P2_CUSTOM                            | -C SMALL                  | -C CACHED_16K             | -C MONO                                                    | -C MHZ_300                              | -C CLOCK                          |
|                |                       |                                         |                        |                            | -lpsram                     |                                         | -C LARGE                  | -C CACHED_32K             | -C COLOR_1                                                 |                                         | -C RTC                            |
|                |                       |                                         |                        |                            | -lhyper                     |                                         |                           | -C CACHED_64K             | -C COLOR_4                                                 |                                         | -C NO_FLOAT                       |
|                |                       |                                         |                        |                            | -lwifi                      |                                         |                           | -C CACHED                 | -C COLOR_8                                                 |                                         | -C NO_ARGS                        |
|                |                       |                                         |                        |                            | -llinenoise                 |                                         |                           |                           | -C COLOR_24                                                |                                         | -C NO_REBOOT                      |
|                |                       |                                         |                        |                            |                             |                                         |                           |                           | -C NO_HMI                                                  |                                         | -C NO_EXIT                        |
|                |                       |                                         |                        |                            |                             |                                         |                           |                           |                                                            |                                         | -C NO_LUT                         |
|                |                       |                                         |                        |                            |                             |                                         |                           |                           |                                                            |                                         | -C P2_REV_A                       |
|                |                       |                                         |                        |                            |                             |                                         |                           |                           |                                                            |                                         | -C OPTIMIZE                       |

### All Command Line Options:

|           |                                                                           |           |                                                          |
|-----------|---------------------------------------------------------------------------|-----------|----------------------------------------------------------|
| -? or -h  | print this help (and exit)                                                | -W option | option to pass directly to LCC                           |
| -B baud   | baud rate to use for serial interfaces (P2 only)                          | -x layout | use specified segment layout (layout = 0 .. 6, 8 .. 11)  |
| -c        | compile only (do not bind)                                                | -y        | generate listing file                                    |
| -d        | output diagnostic messages                                                | -Y        | preprocess only (do not compile)                         |
| -C symbol | define a Catalina symbol (e.g. -C NO_GAMEPAD)                             | -z        | don't invoke the parallelizer on input files that follow |
| -D symbol | define a symbol (e.g. -D printf=tiny_printf)                              | -Z        | invoke the parallelizer on input files that follow       |
| -E        | allowable frequency error (default is 100k)                               |           |                                                          |
| -f freq   | required clock frequency (see also -F & -E                                |           |                                                          |
| -F freq   | crystal frequency (default is 20M)                                        |           |                                                          |
| -g[level] | generate debugging information (default level = 1)                        |           |                                                          |
| -H addr   | address of top of heap                                                    |           |                                                          |
| -I path   | path to include files (default 'C:\Program Files (x86)\Catalina\include') |           |                                                          |
| -k        | kill (suppress) statistics output                                         |           |                                                          |
| -l lib    | search library lib when binding                                           |           |                                                          |
| -L path   | path to libraries (default 'C:\Program Files (x86)\Catalina')             |           |                                                          |
| -M size   | maximum memory size (use with -x)                                         |           |                                                          |
| -o name   | name of output file (default is first file name)                          |           |                                                          |
| -O[level] | optimize code (default level = 1)                                         |           |                                                          |
| -p ver    | Propeller hardware version 1 or 2 (1 is the default)                      |           |                                                          |
| -q        | enable quick build (re-use any existing target files)                     |           |                                                          |
| -P addr   | address for Read-Write segments                                           |           |                                                          |
| -R addr   | address for Read-Only segments                                            |           |                                                          |
| -S        | compile to assembly code (do not bind)                                    |           |                                                          |
| -t name   | name of dedicated target to use                                           |           |                                                          |
| -T path   | path to target files (default 'C:\Program Files (x86)\Catalina\target')   |           |                                                          |
| -U symbol | undefine symbol (e.g. -U DEFAULT)                                         |           |                                                          |
| -v        | verbose (output information messages)                                     |           |                                                          |
| -v -v     | very verbose (more information messages)                                  |           |                                                          |