
Sensor Station Assembly Guide

Rev 1.0 – RG – 22nd May 2015

Parts



- A 1x Spacer 3mm Nylon M3 (BOM item 25).
- B 2x Light pipes (Bom item 22)
- C 4x Screws 4x5/8 Black thread forming (BOM item 24) Customer supplied.
- D 1x Enclosure base (BOM item 23) Customer supplied.
- E 1x Enclosure lid (BOM item 23) Customer supplied.
- F 1x Assembled PCB (old revision pictured, no flying leads on final revision).

Step 1 – Place assembled PCB **F** into enclosure base **D**.



Step 2 – Place light pipes **B** into enclosure lid **E**.



Step 3 – Insert one screw **C** into enclosure lid **E** as shown pictured. Then place spacer **A** on to screw as shown pictured.



Step 4 – Place enclosure lid **E** on to screw holes in enclosure base **D** as shown pictured.



Step 5 – Place the three remaining screws **C** in to screw holes in enclosure lid **E**.



Step 6 – Screw down all four screws **C** until tight. Enclosure manufacturer recommends 4 lbs.in torque.



Assembly complete.