ADH8066

FTP AT Command Reference Supplemental

AT+AFTPCD

Change folder and query current folder.

Ex: Change folder: AT+AFTPCD="/FTPDATA", change to folder /FTPDATA

EX: Query current folder: AT+AFTPCD?, query current folder.

AT+AFTPMKD

Create a new folder.

Ex: create folder, AT+AFTPMKD="/testFTP", create "testFTP" folder at root directory

AT+AFTPRMD

Delete an existing empty folder (does not include any files in the folder)

Ex: delete folder, AT+AFTPRMD="/testFTP", delete "testFTP" folder at root directory.

AT+AFTPDELE

Delete one existing file.

Ex: delete file, AT+AFTPDELE="stortest01.txt", delete the file

("stortest01.txt") at current folder.

Ex: delete file, AT+AFTPDELE="/stortest01.txt", delete the file

("stortest01.txt") at root folder.

Ex: delete file, AT+AFTPDELE="/testFTP/stortest01.txt", delete the

file("stortest01.txt") at "testFTP" folder.

AT+AFTPSTOR

store file into FTP site.

Ex: upload (or called store) file to FTP site,

(PS: AT+AFTPTYPE would be set before.)

(PS; AT+AFTPPASV=1 would be set each time.)

AT+AFTPSTOR="/testFile/storfile.txt"

+AFTPSTOR: "/ testFile/stor20.txt" File Data Ready

OK

AT+AFTPDATA

CONNECT

...SEND DATA until "+++" string input to end the file upload OK

Sample Code:

OK

```
// logon GPRS network
AT+AIPDCONT="Internet"
+AIPDCONT: "Internet", "", ""
OK
// Get GPRS service
AT+AIPA=1
+AIPA: 1,116.59.67.33,0,0,0
// logon ftp server
AT+AFTPO="59.120.15.229",21,"amod","amodftptest"
+AFTPO: Login On
OK
// set transfer data type
AT+AFTPTYPE=0
+AFTPS: 200 Type set to I
+AFTPTYPE: 0
OK
// set trensfer data mode
AT+AFTPPASV=1
+AFTPS: 227 Entering Passive Mode (59,120,15,229,254,80)
+AFTPPASV: 1
OK
// setting file information which upload data to ftp server
AT+AFTPSTOR="/amodtest.txt"
+AFTPS: 150 Connection accepted
+AFTPSTOR: "/amodtest.txt" File Data Ready
OK
// upload data to ftp server
AT+AFTPDATA
CONNECT
.... <Upload data to FTP server> ...
// Close ftp connection
AT+AFTPC
+AFTPC: 0
```