10035 Winkler Dr., St. Louis, MO 63136

| To-do lists |
|---|
| VB Office |
| ■ LB Code 2994 |
| Scope by Bob Pavelka |
| ■ 3 Deadbolts |
| Utilities Electric-Off |
| ☐ Utilities Gas-Off |
| Utilities Water-Off at Basement Service Entrance Valve |
| Contract |
| ■ Windows - 0 |
| Glass Block - 2, 1 w/vent |
| HVAC - R/R AC, Service Furnace |
| Appliances - Hood-White |
| Dumpster - 30 Yd |
| VB Overall |
| Final Clean |
| ☐ Drain Clean |
| ■ Water Heater-R/R WH |
| AC Cage-Add AC Cage at New Install of AC |
| Refinish Hardwood Flooring |
| Add LVT |
| Exterior Front |
| Paint exterior door -Exterior VB Blue - interior, trim and jamb - white add passage handle and deadbolt |
| R&R Mailbox |
| R&R address numbers - black, above mailbox |
| R&R light/ carriage - black |
| Remove all trash, debris |
| ☐ Test Spigot - Report Issues to PM |
| Remove and replace storm door |
| Repair/Place blocks around tree |
| Add railings to porch |
| Add splash blocks to downspouts |

Exterior Rear

Exterior Right

Remove all trash, debris

Add a cage to AC Unit-VB

2/19/2020

Remove and replace exterior door

Paint exterior door -Exterior VB Blue - interior, trim and jamb - white add passage handle and deadbolt

Remove all trash, debris

Remove storm door/hardware and seal holes

Remove dish/Cables - seal holes

Remove basement windows and replace with glass blocks-(1)-VB

Trim overhanging tree branches so they are at least 10 feet from the house

Clear yard growth from all fence lines

Patch old vent pipe

Exterior Left

Remove all trash, debris

Repair gate in fence

Remove and replace exterior door

Paint exterior door -Exterior VB Blue - interior, trim and jamb - white add passage handle and deadbolt

2/6

Remove storm door, seal holes

R&R Light / Black Jelly Jar

General

See "General Scope Items" on Contract

Unfasten ceiling and vanity lights (hang by wires) prior to painting

Remove all electrical cover plates prior to painting

Remove the latches/handles/plates on doors prior to painting

All door must function properly - adjust / trim as needed

Install door stops on all doors

Paint all floor registers - brown

| | Paint all wall registers - white |
|-----|---|
| | Remove all cable, phone jacks, alarm components in every room |
| | Vacuum debris from all floor vents |
| | GC to perform full construction clean after punch out is completed |
| | Clean and seal all guttering and ensure they are properly secured |
| | Clear yard growth from all fence lines |
| | Remove any grass from cracks in driveway. Seal all driveway cracks. |
| | Wash siding |
| Liv | ing Room |
| | Patch and Paint: walls, ceiling, trim, doors- both sides, closets |
| | Check all outlets and switches for proper function. Replace covers, devices and switches so they are matching per room |
| | Remove existing window treatment hardware, seal holes and hang new blinds |
| | Refinish hardwood flooring-VB |
| Kit | chen |
| | Remove all trash and debris |
| | Patch and Paint: walls, ceiling, trim, doors- both sides, closets |
| | Check all outlets and switches for proper function. Replace covers, devices and switches so they are matching per room - Kitchen to have at least on GFCI |
| | Provide stoppers for sink |
| | Check all plumbing / drains and report issues to PM |
| | Remove existing window treatment hardware, seal holes and hang new blinds |
| | Remove existing light fixtures and replace with 13" round fixtures-2 |
| | Add LVT flooring-VB |
| | Add a door to the basement stairs |
| | Add a passage handle to door after painting |
| | Add a Hood-VB |
| | Unpack and install hood |
| | Add a hood plug-VB |
| | Install new cabinets over range for hood support |
| | Paint all cabinets-White |
| | Install cabinet/drawer pulls in proper location - opposite side of door hinge. On bottom corner of upper cabinets, on top corner of lower cabinets, in center of drawers. Ask first if unsure of location |
| | Remove wall decorations, patch holes |
| Ha | II |
| | Remove the latches/handles/plates on doors prior to painting |

| | 10000 William DI., Ot. Eduis, We 00100. 10-40 lists |
|-----|---|
| | Add CO detector mounted on wall 55" above the floor |
| | Add Smoke Detector - Photo electric type mounted on ceiling |
| | R&R passage handle on closet door - install new knob after painting |
| | Check all outlets and switches for proper function. Replace covers, devices and switches so they are matching per room |
| | Remove existing light fixture and replace with 13" round fixture |
| | Remove all trash and debris |
| | Refinish hardwood flooring-VB |
| | |
| Bat | throom-Main Hall |
| | Remove the latches/handles/plates on doors prior to painting |
| | Patch and Paint: walls, ceiling, trim, doors- both sides, closets |
| | Check all outlets and switches for proper function. Replace covers, devices and switches so they are matching per room. Bathroom to have at least one GFCI |
| | Check all plumbing / drains and report issues to PM |
| | R&R privacy handle on entry door - install new handle after painting door |
| | Apply fresh caulk to tub area |
| | Remove existing window treatment hardware, seal holes and hang new blinds |
| | Remove all trash and debris |
| | Add LVT flooring-VB |
| | Add a shower rod and liner |
| | Add a towell bar and TP roller |
| | Remove and replace medicine cabinet |
| | Remove and replace shower head |
| | Add stopper to sink |
| | |
| Bed | droom 1-Front Middle |
| | Remove all trash and debris |
| | Remove the latches/handles/plates on doors prior to painting |
| | Patch and Paint: walls, ceiling, trim, doors- both sides, closets |
| | R&R privacy handle on entry door - install new handle after painting door |
| | Check all outlets and switches for proper function. Replace covers, devices and switches so they are matching per room |
| | Add Smoke Detector - Ion type - Install at ceiling near the door – open door at 45 degree angle and install detector on ceiling directly above end of door. |
| | Remove existing window treatment hardware, seal holes and hang new blinds |
| | Remove existing light fixture and replace with 13" round fixture |
| | Refinish hardwood flooring-VB |

Bedroom 2-Right Front

| | Remove all trash and debris |
|-----|---|
| | Remove the latches/handles/plates on doors prior to painting |
| | Patch and Paint: walls, ceiling, trim, doors- both sides, closets |
| | R&R privacy handle on entry door - install new handle after painting door |
| | Add Smoke Detector - Ion type - Install at ceiling near the door – open door at 45 degree angle and install detector on ceiling directly above end of door. |
| | Check all outlets and switches for proper function. Replace covers, devices and switches so they are matching per room |
| | Remove existing window treatment hardware, seal holes and hang new blinds |
| | Remove existing light fixture and replace with 13" round fixture |
| | Refinish hardwood flooring-VB |
| | |
| Bed | droom 3-Right Rear |
| | Remove the latches/handles/plates on doors prior to painting |
| | Patch and Paint: walls, ceiling, trim, doors- both sides, closets |
| | R&R privacy handle on entry door - install new handle after painting door |
| | Add Smoke Detector - Ion type - Install at ceiling near the door – open door at 45 degree angle and install detector on ceiling directly above end of door. |
| | Check all outlets and switches for proper function. Replace covers, devices and switches so they are matching per room |
| | Remove existing window treatment hardware, seal holes and hang new blinds |
| | Remove existing light fixture and replace with 13" round fixture |
| | Remove all trash and debris |
| | Refinish hardwood flooring-VB |
| | |
| Bas | sement |
| | Remove all trash and debris |
| | Remove walls doors and ceilings, leave walls at stairs |
| | Add smoke detector - Photo electric type mounted on ceiling at bottom of stairs |
| | R&R Water Heater with expansion tank/downtube/on pavers - VB |
| | Check all devices-R&R as needed-1 color-for washer/junction boxes covered/keyless light fixtures on switch or pull chain |
| | Service furnace-VB (leave 3 spare filters) |
| | Paint exterior walls-sealer white |
| | Paint floors & stair treads/risers with porch & floor gray |
| | Check all plumbing / drains and report issues to PM |
| | Remove basement windows, replace with glass block - VB |
| | Add ridged dryer vent. Extend to floor, secure. |
| | Close flue and remove insert, if applicable. Seal fireplace opening with plywood, paint black. |