

FOREWORD

THE SIMBAD POST-PROCESSING PROGRAM PROVIDES, FROM THE SIMBAD CALCULATION RESULTS:

- PLOTS OF TIME SERIES OF MOORING LINE AND FENDER LOADS
- PLOTS OF MOTIONS, SPEEDS AND ACCELERATIONS AT THE CENTER OF GRAVITY AND AT OTHER POSSIBLE POINTS OF THE SHIP

THESE RESULTS CAN BE ALSO POST-PROCESSED, IN ORDER TO OBTAIN:

- TABLES OF RESULTS, INCLUDING:
 - \blacktriangleright Minimum and maximum values over the time series, F1/3 and F1/10 values that are the mean of 3^{RD} or 10^{TH} highest part of the time series distribution
 - ➤ FOR MOTIONS, SPEEDS AND ACCELERATIONS, THE MAXIMUM AND MINIMUM STATISTICAL VALUES GIVEN RESPECTIVELY BY: AVERAGE VALUE + OR − 3.8 X STANDARD DEVIATION

NOTICE

Any software and information, including technical and engineering data, figures, tables, designs, drawings, details, procedures and specification, presented herein or elsewhere are for general information only. While every effort has been made to insure its accuracy, any software and information should not be used or relied upon for any specific application without independent competent professional examination and verification of its accuracy, suitability and applicability, by a qualified professional engineer (e.g. qualified engineer in the field of hydraulics or hydrodynamics).

This product (any software and information) is provided "as it is", without warranty of any kind. Anyone making use of this material (any software and information) does so at his own risk and assumes any and all liability resulting from such use. The entire risk as to quality or usability of the material contained within is with the reader and user. In no event, will the author(s) be held liable for any direct or indirect damages including lost profits, lost savings, loss of business information or other incidental or consequential damages arising from the use of or inability to use any software and information contained within.


THE INPUT DATA ARE READ FROM THE SIMBAD OUTPUT FILES: "*.RES"

RESULTS ARE WRITTEN INTO DIFFERENT OUTPUT FILES:

- ➤ "MAX_MIN.TXT", FOR MOORING LINE AND FENDER LOADS
- **►** "MOTIONCG.TXT", FOR THE MOTIONS, VELOCITIES OR ACCELERATIONS OF CENTRE OF GRAVITY
- ➤ "MOTIONPT.TXT", FOR THE MOTIONS, VELOCITIES OR ACCELERATIONS OF A SPECIFIC POINT

THESE FILES ARE DESCRIBED IN DETAILS HEREAFTER.

RUNNING THE SIMBAD POST-PROCESSING PROGRAM: AN EXAMPLE OF RUN IS GIVEN HEREAFTER



RUNNING THE SIMBAD POST-PROCESSING PROGRAM: RESULT FILE "MAX_MIN.TXT", FOR MOORING LINE AND FENDER LOADS

		Forces		7
Line n°	: Min	Max	F1/3	F1/10
1	0.00	112.10	65.15	77.77
2	0.00	118.40	68.84	82.36
3	0.00	113.80	66.07	78.82
4	17.99	42.29	32.02	34.48
5	16.55	50.38	36.81	40.20
6	0.00	153.30	84.34	101.36
7	0.00	158.60	86.85	104.66
8	0.00	151.50	83.51	100.69
9 -	-1521.00	0.00	-813.07	-1013.06
10 -	-1720.00	0.00	-890.24	-1125.18

MINIMUM AND MAXIMUM VALUES, F1/3 AND F1/10 VALUES

RUNNING THE SIMBAD POST-PROCESSING PROGRAM: RESULT FILE "MOTIONCG.TXT", FOR THE MOTIONS, VELOCITIES OR ACCELERATIONS OF CENTRE OF GRAVITY

Motion						
Type:	Min	Max	Minst.	Maxst.	F1/3	F1/10
SURGE	-0.049	0.0724	-0.062	0.0815	0.0458	0.0567
SWAY	-2.676	1.12	-2.193	1.6435	-1.274	-1.668
HEAVE	-1.281	1.381	-1.284	1.2818	-0.671	-0.857
ROLL	-3.81	3.443	-3.760	3.5198	-2.010	-2.520
PITCH	-0.034	0.0414	-0.037	0.0403	0.0220	0.0274
YAW	-0.494	0.3937	-0.498	0.4167	-0.268	-0.335

MINIMUM AND MAXIMUM VALUES, MAXIMUM AND MINIMUM STATISTICAL VALUES, F1/3 AND F1/10 VALUES

RUNNING THE SIMBAD POST-PROCESSING PROGRAM: RESULT FILE "MOTIONPT.TXT", FOR THE MOTIONS, VELOCITIES OR ACCELERATIONS OF A PARTICULAR POINT

Motion							
Type:	Min	Max	Minst.	Maxst.	F1/3	F1/10	
X	-2.772	1.215	-2.763	1.7640	-1.423	-1.761	
Υ	-1.156	0.5952	-0.981	0.6425	-0.556	-0.728	
Z	-0.986	0.7788	-0.849	0.7255	-0.469	-0.584	

MINIMUM AND MAXIMUM VALUES, MAXIMUM AND MINIMUM STATISTICAL VALUES, F1/3 AND F1/10 VALUES