- -> Why are ratings important? Characterize speed of performance, stability, accuracy; used in modelling to predict system performance and the effects of interconnection.
- -> What if an analytical model is not possible? A linear system is one that can be expressed by a linear analytical model; if error or non-linear phenomena cause the system to be nonlinear, linearize (according to the textbook)
 - Also: analyze system, create model, simulate system, design, test
- Applications of instrumentation: process monitoring, testing and qualification, product quality assessment, fault prediction, detection and diagnosis, warning generation, surveillance, model identification, control
- Sensor = measures unknown signals and parameters of a plant and its environment
- Sensor system = 1) many sensors, sensor fusion, 2) sensor + accessories (signal processing, DAQ, display,...)
- Examples of sensors:
 - Motion potentiometer, LVDT, magnetostrictive, tachometer, resolver, ultrasound ranger
 - Force/torque strain gauge, motor current sensor
 - Flow pitot tube, rotameter, orifice flow meter
 - Pressure manometer, bourdon tube, diaphragm type
 - Pressure and flow can be correlated; sensors can be interchanged
 - Temperature thermocouple, thermistor, RTD
- Kinds of impedance
 - Across variable / Thru variable
 - Electrical: voltage/current
 - Mech: velocity/force, called MOBILITY 0
- Problems with signals
 - Noise: filter it
 - Drift (stable conditions but signal shifts): condition it
 - Low signal level/power: amplify it
 - Other fixes: signal modification (filtering), modulation (overlay signal on carrier waveform), error detection and encoding, signal conversion (ADC, DAC)
- Instrumentation = adding/integrating devices into a system so that you achieve desired system performance
- -> Benefits/drawbacks of mech compared to elec components? Weight, inertia, cost, size, obviousness of hazards (electrocution)
- MEMS Devices: small size and light weight (negligible loading errors), high speed (high bandwidth), convenient for mass production (low cost)
- Characteristics of a mechatronic system
 - Electromechanical
 - Has sensors, actuators, controllers
 - Multiphysics, multidomain, and designed with all domains/components considered simultaneously
 - Optimized and designed through the mechatronics approach
- Mechatronics approach key points: electromechanical (de Silva expands to multi-physics) products and systems, integrated design, and a bunch of other bullshit
- Instrumentation is an integral part of design
- Terminology
 - Most of the stuff on the slide is obvious
 - Feed-forward control: control signal is determined according to plant excitation (or model) without knowing actual output
- Steps: 1) study system, 2) identify and group components based on domain, 3) develop a preliminary system

- architecture, 4) create model, 5) get performance requirements of system
- Based on what components are actually found, model and system architecture may need to be revised.
- Design process: 1) identify basic components in conceptual design, 2) determine sensor parameter values in detailed design, optimize
- Design process may indicate a commercially unavailable product needs to be developed
- Dynamic coupling = connecting components changes their behavior compared to when they operate independently
- Generalized impedance = across / through
 - Across variables: voltage, velocity, pressure, temperature
 - Through variables: force, current, fluid flow rate, heat transfer rate
- Goal of impedance matching:
 - Source and Load matching for max power transfer
 - Power transfer at maximum efficiency
 - Reflection prevention in signal transmission
 - Loading reduction
- All components of system have effect on signals (sensors, signal conditioning circuits, actuators, cables, support structure, etc.)
 - Ex. Mechanical power flow involves angular velocity, torque, ...

Electrical power flow - involves voltage and

Impedance matching may be needed to reach desired operating conditions; type of matching depends on goal and system

Note: at max power, efficiency=50%

DC (pure resistance)

$$i = \frac{v_s}{R_l + R_s}$$
$$v_l = iR_l = \frac{v_s R_l}{R_l + R_s}$$

Power absorbed by load:

$$p_{l} = iv_{l} = \frac{v_{s}^{2} R_{l}}{[R_{l} + R_{s}]^{2}}$$

Max power if: $\frac{dp_l}{dR_l} = 0$ Occurs when $R_I = R_s$

General Impedance

General impedance
$$|I| = \frac{|V_s|}{|Z_l + Z_s|}$$

$$p_l = I_{rms}^2 R_l = \frac{1}{2} |I|^2 R_l$$


$$= \frac{1}{2} \frac{|V_s|^2}{|Z_l + Z_s|} R_l$$

$$= \frac{1}{2} \frac{|V_s|^2}{(R_l + R_s)^2 + (X_l + X_s)^2} R_l$$
 (resistive and reactive parts can be

(resistive and reactive parts can be adjusted independently)

Max power if: $Z_l = Z_s^*$

Max power $p_{l,max} = \frac{|V_s|^2}{8R_s} = \frac{|V_s|^2}{8R_l}$




Note: z=a+bi, z*=a-bi $Z_L = j\omega L$ $Z_C = \frac{1}{j\omega C}$

Power transfer at max efficiency

Eff=absorbed/total power


As $R_L \to \infty$, $\eta \to 1$

$$\eta = \frac{R_L}{R_L + R_S} = \frac{1}{1 + \frac{R_S}{R_L}}$$




Impedance matching to prevent signal reflection

- Abrupt change in impedance reflects signals
- Reflection deteriorates signal (magnitude and phase), and dissipates power
- Match impedance on transmission lines to prevent reflection



Impedance Matching for Loading Reduction

 Sensor should not significantly change system behavior; loading error is one of the biggest errors




• Ex. Force or motion isolation for stuff sensitive to vibration

Element	Time Domain	Impedance	Mobility
Mass m	$m\frac{dv}{dt} = f$	$Z_m = ms$	$M_m = \frac{1}{ms}$
Spring k	$\frac{df}{dt} = kv$	$Z_k = \frac{k}{s}$	$M_k = \frac{s}{k}$
Damper b	f = bv	$Z_b = \overline{b}$	$M_b = \frac{1}{b}$

 Force transmissibility=velocity of mass under investigation/driving velocity = force

$$T_m = \frac{v_m}{v} = \frac{M_m}{M_m + M_s} = \frac{Z_s}{Z_s + Z_m} = T_f$$




Maximum power transfer when the forcing is at natural frequency

(resonance), but amplitude is not at max; max power transfer implies max motion and force transmissibility

- $\circ r = rac{\omega}{\omega_n}$, for small ζ , peak transmissibility at r pprox 1
- As ζ increases, peak shifts to lower r
- \circ "isolation" after resonance peak, when $|T_f|<1$ which occurs when r>sqrt(2); after this $|T_f|$ increases with ζ
- o Percent isolation $I = [1 |T|] \times 100\%$

Part 4: Op-amps (s6)

- ideally, K=infinity, Zi=infinity, low Zo
- With negative feedback, inputs to op-amp are ~equal



- -> Why are ratings important? Characterize speed of performance, stability, accuracy; used in modelling to predict system performance and the effects of interconnection.
- -> What if an analytical model is not possible? A linear system is one that can be expressed by a linear analytical model; if error or non-linear phenomena cause the system to be nonlinear, linearize (according to the textbook)
 - Also: analyze system, create model, simulate system, design, test
- Applications of instrumentation: process monitoring, testing and qualification, product quality assessment, fault prediction, detection and diagnosis, warning generation, surveillance, model identification, control
- Sensor = measures unknown signals and parameters of a plant and its environment
- Sensor system = 1) many sensors, sensor fusion, 2) sensor + accessories (signal processing, DAQ, display,...)
- Examples of sensors:
 - Motion potentiometer, LVDT, magnetostrictive, tachometer, resolver, ultrasound ranger
 - Force/torque strain gauge, motor current sensor
 - Flow pitot tube, rotameter, orifice flow meter
 - Pressure manometer, bourdon tube, diaphragm type
 - Pressure and flow can be correlated; sensors can be interchanged
 - Temperature thermocouple, thermistor, RTD
- Kinds of impedance
 - Across variable / Thru variable
 - Electrical: voltage/current
 - Mech: velocity/force, called MOBILITY 0
- Problems with signals
 - Noise: filter it
 - Drift (stable conditions but signal shifts): condition it
 - Low signal level/power: amplify it
 - Other fixes: signal modification (filtering), modulation (overlay signal on carrier waveform), error detection and encoding, signal conversion (ADC, DAC)
- Instrumentation = adding/integrating devices into a system so that you achieve desired system performance
- -> Benefits/drawbacks of mech compared to elec components? Weight, inertia, cost, size, obviousness of hazards (electrocution)
- MEMS Devices: small size and light weight (negligible loading errors), high speed (high bandwidth), convenient for mass production (low cost)
- Characteristics of a mechatronic system
 - Electromechanical
 - Has sensors, actuators, controllers
 - Multiphysics, multidomain, and designed with all domains/components considered simultaneously
 - Optimized and designed through the mechatronics approach
- Mechatronics approach key points: electromechanical (de Silva expands to multi-physics) products and systems, integrated design, and a bunch of other bullshit
- Instrumentation is an integral part of design
- Terminology
 - Most of the stuff on the slide is obvious
 - Feed-forward control: control signal is determined according to plant excitation (or model) without knowing actual output
- Steps: 1) study system, 2) identify and group components based on domain, 3) develop a preliminary system

- architecture, 4) create model, 5) get performance requirements of system
- Based on what components are actually found, model and system architecture may need to be revised.
- Design process: 1) identify basic components in conceptual design, 2) determine sensor parameter values in detailed design, optimize
- Design process may indicate a commercially unavailable product needs to be developed
- Dynamic coupling = connecting components changes their behavior compared to when they operate independently
- Generalized impedance = across / through
 - Across variables: voltage, velocity, pressure, temperature
 - Through variables: force, current, fluid flow rate, heat transfer rate
- Goal of impedance matching:
 - Source and Load matching for max power transfer
 - Power transfer at maximum efficiency
 - Reflection prevention in signal transmission
 - Loading reduction
- All components of system have effect on signals (sensors, signal conditioning circuits, actuators, cables, support structure, etc.)
 - Ex. Mechanical power flow involves angular velocity, torque, ...

Electrical power flow - involves voltage and

Impedance matching may be needed to reach desired operating conditions; type of matching depends on goal and system

Note: at max power, efficiency=50%

DC (pure resistance)

$$i = \frac{v_s}{R_l + R_s}$$
$$v_l = iR_l = \frac{v_s R_l}{R_l + R_s}$$

Power absorbed by load:

$$p_{l} = iv_{l} = \frac{v_{s}^{2} R_{l}}{[R_{l} + R_{s}]^{2}}$$

Max power if: $\frac{dp_l}{dR_l} = 0$ Occurs when $R_I = R_s$

General Impedance

General impedance
$$|I| = \frac{|V_s|}{|Z_l + Z_s|}$$

$$p_l = I_{rms}^2 R_l = \frac{1}{2} |I|^2 R_l$$


$$= \frac{1}{2} \frac{|V_s|^2}{|Z_l + Z_s|} R_l$$

$$= \frac{1}{2} \frac{|V_s|^2}{(R_l + R_s)^2 + (X_l + X_s)^2} R_l$$
 (resistive and reactive parts can be

(resistive and reactive parts can be adjusted independently)

Max power if: $Z_l = Z_s^*$

Max power $p_{l,max} = \frac{|V_s|^2}{8R_s} = \frac{|V_s|^2}{8R_l}$




Note: z=a+bi, z*=a-bi $Z_L = j\omega L$ $Z_C = \frac{1}{j\omega C}$

Power transfer at max efficiency

Eff=absorbed/total power


As $R_L \to \infty$, $\eta \to 1$

$$\eta = \frac{R_L}{R_L + R_S} = \frac{1}{1 + \frac{R_S}{R_L}}$$




Impedance matching to prevent signal reflection

- Abrupt change in impedance reflects signals
- Reflection deteriorates signal (magnitude and phase), and dissipates power
- Match impedance on transmission lines to prevent reflection



Impedance Matching for Loading Reduction

 Sensor should not significantly change system behavior; loading error is one of the biggest errors




• Ex. Force or motion isolation for stuff sensitive to vibration

Element	Time Domain	Impedance	Mobility
Mass m	$m\frac{dv}{dt} = f$	$Z_m = ms$	$M_m = \frac{1}{ms}$
Spring k	$\frac{df}{dt} = kv$	$Z_k = \frac{k}{s}$	$M_k = \frac{s}{k}$
Damper b	f = bv	$Z_b = \overline{b}$	$M_b = \frac{1}{b}$

 Force transmissibility=velocity of mass under investigation/driving velocity = force

$$T_m = \frac{v_m}{v} = \frac{M_m}{M_m + M_s} = \frac{Z_s}{Z_s + Z_m} = T_f$$



Maximum power transfer when the forcing is at natural frequency

(resonance), but amplitude is not at max; max power transfer implies max motion and force transmissibility

- $\circ r = rac{\omega}{\omega_n}$, for small ζ , peak transmissibility at r pprox 1
- As ζ increases, peak shifts to lower r
- \circ "isolation" after resonance peak, when $|T_f|<1$ which occurs when r>sqrt(2); after this $|T_f|$ increases with ζ
- o Percent isolation $I = [1 |T|] \times 100\%$

Part 4: Op-amps (s6)

- ideally, K=infinity, Zi=infinity, low Zo
- With negative feedback, inputs to op-amp are ~equal

