
```
00 Label:
                    Step:
                                                                           Verifica se area in esecuzione o prenotata
      V5b4_b != 0
                                                                                                                   goto(FASE_FIN)
         __ ] > [ ___
                                                                                                                        —(T)-
      %V5b4.B != 0x0
      V5b5_b != 0
        ____]>[____
      %V5b5.B != 0x0
                                                                                  Abilitazione listelli area AB
01 Label:
                    Step:
                                                              Sel_list_ab
                                                                                  V210_1
                                                                                                                          (1)
                                                                — ] / [ —
                                                                                   -F_T-
                                                                                                                        —(T)—
                                                                                  %V210.1
                                                               %I5600.0
                                                                                                      Bdf1_mr56 = Bdf1_mr56 & 126
                                                                                                                       — (Т)—
                                                                                                           Q5601.B = Q5601.B \& 0x7e
                                                                                                             %V18 B = %V18.B & 240
                                                                                                                   —— (T)—
                                                                                                               %V18.B = %V18.B & 0xf0
                                                             Sel_list_ab
                                                                                  V210_2
                                                                                                                          (2)
                                                               — ] [ —
                                                                                   —R_T-
                                                                                                                        —(T)—
                                                               %I5600.0
                                                                                  %V210.2
                                                                                                        Bdf1_mr56 = Bdf1_mr56 | 1
                                                                                                            %Q5601.B = %Q5601.B | 0x1
                                                                                                             %V18.B = %V18.B & 240
                                                                                                                       — (T) —
                                                                                                              %V18.B = %V18.B & 0xf0
   (1) %Q5600.B = %Q5600.B & 0xcf
                                            Bdf0_mr56 = Bdf0_mr56 & 207
```

Bdf0_mr56 = Bdf0_mr56 | 48

Author:		NUM TOOLS		
Company:		NOM	тоопр	
Project: 1040_78.mch	TITRE		Date	28-02-2018
Module: LISTELLI.XLA		%SP126 (00)	Page	1

(2) $\%Q5600.B = \%Q5600.B \mid 0x30$



(2) %Q5600.B = %Q5600.B | 0xc0 : Bdf0_mr56 = Bdf0_mr56 | 192


03 Label: Step:


Selettore lock area A

Sel_list_ab] [App_locka	V210_5	Ab_vent_h.4 () %V17.4
App_1	ockb, Abb_aree_ab 		
App_1	ckb, Abb_aree_ef] [
	Vent_all_on _] [


Mem. abilitazione ventose area H

Author: Company:		NUM TOOLS		
Project: 1040_78.mch	TITRE		Date	28-02-2018
Module: LISTELLI.XLA		%SP126 (02)	Page	2






Author:		NUM TOOLS		
Company:		NOM	100.	по
Project: 1040_78.mch	TITRE		Date	28-02-2018
Module: LISTELLI.XLA		%SP126 (07)	Page	4



Author:		NUM TOOLS		
Company:		NOM	100.	по
Project: 1040_78.mch	TITRE		Date	28-02-2018
Module: LISTELLI.XLA		%SP126 (09)	Page	5



Author:		NUM TOOLS		
Company:		NOM	TOOL	מו
Project: 1040_78.mch	TITRE		Date	28-02-2018
Module: LISTELLI.XLA		%SP126 (11)	Page	6

13 Label: FASE C Step: Blocco / Sblocco area C fase 1 Ab_vent_h.6 %V18.4 %V18.5 Ab_low_c Abilitazione basso vuoto area C —] [— —] / [*-*— (R)-%V17.6 %05600.2 Abilitazione ventose area C - ar Vent cl ___(S)_ %Q4201.0 %V18.4 ——(S)— %V18.5 — (R) goto(FASE_D) —— (T)— Blocco / Sblocco area C fase 2 14 Label: Step: %V18.4 Ab_vent_h.6 %V18.5 Ab_low_c Abilitazione basso vuoto area C —] [— —] / [– — (R)-%V17.6 %Q5600.2 Vent_cl Abilitazione ventose area C - ar — (R)-%Q4201.0 %V18.4 — (S) — %V18.5 —(S)goto(FASE_D) ——(T)—

Author:		NUM TOOLS		
Company:		NOM	10012	•
Project: 1040_78.mch	TITRE		Date	28-02-2018
Module: LISTELLI.XLA		%SP126 (13)	Page	7

15 Label: Step: Blocco / Sblocco area C fase 3 Ab_vent_h.6 %V18.4 %V18.5 Ab_low_c Abilitazione basso vuoto area C —] [— —(S)-%V17.6 %05600.2 Abilitazione ventose area C - ar Vent_cl __(S)_ %Q4201.0 %V18.4 —— (R)— %V18.5 — (R) goto(FASE_D) —— (T)— 16 Label: FASE_D Blocco / Sblocco area D fase 1 Ab_vent_h.7 %V18.6 %V18.7 Ab_low_d Abilitazione basso vuoto area D —] [— —] / [– — (R)-%V17.7 %Q5600.3 Vent_d Abilitazione ventose area D —(S)-%Q4201.1 %V18.6 — (S) — %V18.7 —(R)goto(FASE_FIN) ——(T)—

Author:		NUM TOOLS		
Company:		NOM	1001	5
Project: 1040_78.mch	TITRE		Date	28-02-2018
Module: LISTELLI.XLA		%SP126 (15)	Page	8

17 Label: Step: Blocco / Sblocco area D fase 2 Ab_vent_h.7 %V18.6 %V18.7 Ab_low_d Abilitazione basso vuoto area D —] [— —] / [— —(R)-%V17.7 %05600.3 Abilitazione ventose area D Vent_d — (R)-%Q4201.1 %V18.6 ——(S)— %V18.7 — (S) goto(FASE_FIN) —— (T)— Blocco / Sblocco area D fase 3 **18** Label: Step: %V18.6 %V18.7 Ab_vent_h.7 Ab_low_d Abilitazione basso vuoto area D —] [— —(S)-%V17.7 %Q5600.3 Vent_d Abilitazione ventose area D —(S)-%Q4201.1 %V18.6 — (R)— %V18.7 —(R)goto(FASE_FIN) ——(T)—

Author:		NUM TOOLS		
Company:		NOM	TOOL	io
Project: 1040_78.mch	TITRE		Date	28-02-2018
Module: LISTELLI.XLA		%SP126 (17)	Page	9

19 Label: FASE_FIN Step:

Copyright by...

Author: Company:		NUM TOOLS		
Project: 1040_78.mch	TITRE		Date	28-02-2018
Module: LISTELLI.XLA		%SP126 (19)	Page	10