6809 FORTH — MEMORY MAP

64K ADDRESS SPACE · SUBROUTINE-THREADED · 16-BIT CELL

block heights are log-scaled for legibility — not linear with actual byte size
high addresses at top, low addresses at bottom — standard memory-map orientation
BASECODE end differs by serial build: polled (SERIALPOLL=1, default) / interrupt-driven (SERIALPOLL=0)

$FFFF

VECTORS hardware vectors — $FFF0–$FFFF

INITCODE — $FFA4–$FFEB
COLDSTRT / WARM entry (4 pad bytes to VECTORS)

BASECODE — $DBF0–$FE52 polled
ROM primitives + system words — $DBF0–$FF91 interrupt

BASEDICT — $D322–$DBEF
ROM dictionary headers

(unused) — $C100–$D321
spare ROM — INOUT shadow to BASEDICT

INOUT — $C000–$C0FF
I/O block — ACIA regs at INOUT+8

RSTACK — $BD00–$BFFF
return stack (S) — grows down

DSTACK — $B900–$BCFF
data stack (U) — grows down

$8000

APPCODE — $7000–$B8FF
application code (CODEHERE)
Transient (floating, 128 B above CODEHERE)

$4000

APPDICT — $2000–$6FFF
application dictionary (DPHERE)

$1000

APPVARS — $0240–$1FFF
mutable var space (VARHERE)

SUBPOOL — $0200–$023F
REPLACES substitution table (64 bytes)

OUTBUF — $01C0–$01FF
output ring buffer (interrupt build)

INBUF — $0180–$01BF
input ring buffer (interrupt build)

SERBUFCTL serial indices + error counters — $0176–$017F

(unclaimed) not used for any purpose — $0156–$0175

TIBBUF — $0106–$0155
terminal input buffer (80 bytes)

(unclaimed) — $0100–$0105

GLOBALS — $0000–$00FF
shared system globals — Direct Page (69 of 256 used)

$0000

◀ Direct Page (DP) set to $00 at reset

REGION KEY

- ROM (fixed)
- RAM — grows up
- RAM — grows up (vars)
- Stack — grows down
- Fixed buffer
- I/O / device / serial
- RAM — fixed
- Unused / spare