

RingCast Player: UX scenario

=====

App: RingCast Player (com.netringtech.ringcast) 1.0.0, standard LG webOS TVs, webOS 5 and later
Resolution: 1920x1080. Languages: English (default), Spanish (follows the TV's language).

1. App overview

RingCast Player turns the TV into a digital signage screen for RingCast Manager, a signage server an organisation runs for itself. The app has four kinds of screens: the server address, the pairing code, a short "Screen added" notice, and the content player (full screen). Setup is done once; afterwards the app only plays. There are no menus, lists, accounts or settings screens.

2. Screen list

ID	Screen	Shown when	Controls
S1	Splash	at launch (webOS, appinfo.json splashBackground)	none
S2	Server address	first launch (no server saved); or chosen from S3/S4/S5	address field, Connect
S3	Connecting	while the address is checked	"change the server address" button
S4	Pairing code	server accepted, screen not yet added	"change the server address" button
S5	Message	the server can't be reached or refuses (with the reason; retries by itself)	"change the server address" button
S6	Screen added	for 60 seconds after an administrator added the screen in the dashboard	none
S7	Playing	content from the server, full screen; an "Offline" marker in the corner while the network is down (content keeps playing)	none

Flow: S1 → S2 → S3 → S4 → S6 → S7. Later launches: S1 → S7 (or S4 when not paired yet).
S4/S5 → (OK or BLUE) → S2 pre-filled → BACK → S4/S5.

3. Keys on every screen

Magic Remote pointer	The control under the pointer takes the focus (cyan ring); OK clicks it. OK over an empty area does nothing. The wheel has nothing to scroll (no lists). On S7 the pointer does nothing: content isn't interactive.
Arrow keys	Move the focus between the controls of the screen (S2: field and Connect). Moving with the arrows hides the pointer (webOS).
OK	Selects the focused control.
BACK	S2 opened from S4/S5: back to S4/S5, the server is kept. S2 on first launch, S3, S4, S5, S6: leaves the app (first screen of the app); the next launch continues where it was. S7: leaves the app (see section 5). With the on-screen keyboard open, BACK only closes the keyboard.
EXIT	Closes the app (handled by webOS). The pairing is kept.
HOME	Opens the webOS home screen (handled by webOS); the app keeps its state in the background.
BLUE	S3, S4, S5: same as OK on the button (change the server address).
RED, GREEN, YELLOW, number keys, INFO	Do nothing on every screen.
Volume, mute, channel	Handled by the TV; the app does not use them.

4. Screen by screen

S2 Server address

Elements: title "Connect to your signage server", the address field (pre-filled "https://"), the Connect button, an example address, a key hint line, and at the bottom the app version, platform and TV model.

Focus starts on the field. OK opens the TV's on-screen keyboard; "Done"/OK on the keyboard closes it and moves the focus to Connect. OK on Connect checks the address. Arrow DOWN or RIGHT goes to Connect, UP or LEFT back to the field.
Wrong address: the reason is shown under the field in plain words (not https, an IP address or local name, server unreachable or its certificate not trusted, not a signage server). The focus stays on the screen; correct the address and press Connect again.

S3 Connecting

"Connecting to <server>..." while a server address supplied with the app is checked (signage installs) or while pairing starts. Without a network it gives up after about 30 seconds and shows S2 or S5 with the reason.

S4 Pairing code

A large code such as HXRT-2B99 and "Enter this code in RingCast Manager, Screens → Add Screen". A new code appears by itself when one expires. The button at the bottom left (focused) changes the server address.

S5 Message

Title and reason (for example "Can't reach the server"), and "Retrying in N s...". The app retries by itself (every 5 seconds at first, up to every 5 minutes).

S6 Screen added

"Screen added", the screen's name, "Claimed by <account>", the server, and a countdown of 60 seconds before playing starts. No keys needed.

S7 Playing

The server's content full screen. No on-screen controls. A small "Offline" marker appears in the bottom right corner (inside the safe area) while the server can't be reached; the content keeps playing and the marker goes away when the server answers again.

5. BACK on the playing screen (S7)

S7 is the app's main screen once set up, and it has no previous screen, so BACK leaves the app the webOS way (the TV shows what it showed before, or the home screen). The pairing is kept: opening RingCast Player again plays at once.

On a TV used as signage, the organisation's server can bring RingCast Player back to the front: when an administrator has connected "TV control" for that screen in the server's dashboard (it uses LG Connect Apps on the TV), the server reopens RingCast Player within about 10 seconds whenever another app or input is in front. Without that connection (as on a test TV) RingCast Player stays in the background until it is opened again. This is the organisation's choice, made on its server; the app itself never starts on its own.

LG webOS Signage displays use a separate package (not the store app), where BACK on S7 is ignored because those displays play unattended.

6. Resilience

No network at launch	Not set up yet: S2 works as usual; Connect explains "Can't reach <server>" under the field. Set up: S7 with the "Offline" marker and the reason the player can't start; retries by itself and plays as soon as the server answers. While pairing: S4/S5 retry by themselves. No hang, no blank screen, and BACK, EXIT and HOME always work.
Network lost while playing	Content keeps playing, "Offline" marker; recovers by itself.
TV power off/on, unplug	The pairing is saved on the TV. On the next launch the app goes straight to S7 (or S4 if it wasn't added yet).
HOME and back	The app resumes where it was.