CHASE!

CHASE! is a two-person competitive game using two Cromemco JS-1 joystick consoles. The game display is generated on a color TV using the Cromemco Dazzler TV interface.

The game begins with a cross and a circle in opposite corners of the playing field. One joystick controls the cross, the other the circle. The object is for the cross to catch the circle. The game score is automatically kept as is the time remaining. The player controlling the cross gains a point every time he catches the circle. When the time for the first half of the game is exhausted, the second half can be entered by depressing button number two on the joystick console. During the second half of the game, the second player now controls the cross and gains points as he catches the circle (now controlled by the first player). At the end of the game, the score of both players is displayed on the screen.

The game is begun by pushing switch number one on the joystick console. The game can be restarted at any time by pushing button number four on the joystick console.