

1967/1968

P. Traynor, et. al.

Ø

Public Domain

NOTE 1 All ceramic caps in this stage were replaced by silver mica or film/foil orange drop types. NOTE 2 Move LOAD LINES horizontally to match 0mA plate current with measured PRE voltage.