

BingPi-M2外扩引脚说明

			3.3V PWR				
TWI3-SDA	UART5-RX	PE7		5V PWR			
TWI3-SCK	UART5-TX	PE6		5V PWR			
		NC		GND			
		GND		PE5	UART4-RX	TWI2-SDA	
TWI0-SCK	UART2-TX	PE2		PE4	UART4-TX	TWI2-SCK	
TWI0-SDA	UART2-RX	PE3		PE8	UART1-RTS	PWM2	UART3-TX
	UART1-RX	PE11		GND			
		3.3V PWR		PE9	UART1-CTS	PWM3	UART3-RX
TWI1-SCK	UART2-RTS	PE0		PE10	UART1-TX	PWM4	
TWI1-SDA	UART2-CTS	PE1		GND			
		NC		PE12	TWI2-SCK		
		GND		PE13	TWI2-SDA	PWM5	
		USB-DM4		5V PWR			
		NC		USB-DP4			
		LINEINL		GND			
		TVOUT		LINEINR			
		TVIN1		GND			
		NC		TVIN0			
		GND		NC			
				GPADC0			